


1

# Screen Printing Machine V 2002 EX/ Spider/ Easy OPERATING GUIDE



## HEINZ WALZ GMBH

Maybachstr. 3  
72793 Pfullingen  
Germany

☎: (00 49) 71 21/ 92 98-0  
Fax: (00 49) 71 21/ 92 98-60

info@walz-gmbh.de  
www.walz-gmbh.de

## 1- Safety notes:

### Generalities:

#### **Observe notes in the operating manual**

The pre requisite for safe handling and trouble free operation of this machine is the knowledge of the fundamental safety regulation.

This operating manual contains the most important notes for safe operation of the machine.

The operating manual and the safety notes in particular, must be observed by all persons working on the machine.

In addition, the rules and regulations for accident prevention valid for the operating site must be observed.

### Employer/ management:

#### **Obligations of the employer/ Management**

The employer/ management is obliged only to have persons working on the machine who:

- are familiar with the regulation on industrial safety and accident prevention and are instructed in the handling of the machine.
- have read, understood and confirmed by signature the safety chapter and the warning notes in this operating manual
- The safety conscious actions of the personnel will be checked by the operator at regular intervals.

### Employees/ Operator:

#### **Obligations of the employee/ Operator**

Persons employed to work on the machine are obliged before commencing work:

- to observe the industrial safety regulations and rules of accident prevention.
- to read the safety chapter and the warnings in this operating manual and confirm that they have understood them by signing.

### Machine:

#### **Danger when handling the machine**

The screen printing machines Schenk Spider and Variprint 2002CX have been constructed according to the latest state of the art and the recognized technical safety rules. The machine may only be used :

- for the purpose it was intended
- in perfect condition with respect to its technical safety devices.

Improper use may lead to danger to the life and limb of the user or third persons or damage to the machine or other material damages.

Faults which may affect the safety must be eliminated immediately.

**Use :****Proper use of the machine:**

The exclusive purpose of the screen printing machines Spider and Variprint 2002CX is the multicolour printing of textiles, synthetics and paper. Any other use of the machine will be considered as improper. The company Heinz WALZ GmbH will not be liable for damages resulting from such use. Proper use also includes

- observing all the instructions in the operating manual
- carrying out all inspections and maintenance work

**Warranty and liability:****Warranty and liability.**

The « General Terms of Sale and Delivery » of the company *Walz GmbH Textilmaschinen* apply systematically. These are available to the operator at the latest since concluding the contract. Warranty and liability claims in the event of personal injury and material damages are excluded if these are due to one or more of the following causes:

- improper use of the machine
- improper assembly, commissioning, operating and maintenance of the machine
- operation of the machine with defective and/or non functioning safety and protective devices
- failure to observe the instructions in the operating manual with respect to transport, storage, assembly, commissioning, operation and maintenance of the machine
- unauthorized constructional alterations to the machine
- unauthorized alteration of the drive condition( Performance etc.)
- poor monitoring of machine parts which are subject to wear
- repairs improperly done and/or use of non original or non adequate spare parts
- Catastrophes due to the influence of foreign bodies and force majeure.

## 1.1- Safety Regulations :

### Symbols and notices :

#### Explanation of the symbols and notices

The following designations and signs are used for danger or warnings:



#### **DANGER**

This symbol means an imminent threat to the life and health of persons.  
Failure to observe these instructions may result in serious damage to the health and even potentially fatal injury.




#### **WARNING**

This symbol means a possible threat to the life and health of persons.  
Failure to observe these instructions may result in serious damage to the health and even potentially fatal injury.



#### **CAUTION**

This symbol means a potentially dangerous situation.  
Failure to observe these instructions may result in minor injury or material damage.



#### **NOTE**

Under this symbol, you will receive hints, tips and useful information.  
They help you to use the machine functions correctly and optimally.

## 1.2- Basic safety precautions:

**Avoid wearing loose clothing**, non attached long hair, neck ties etc., when operating the machine as these can easily become entangled in moving parts ( Rotating parts, squeegees cylinders etc.). The wear of safety shoes is recommended.

**Do not operate the machine if you are sick**, excessively tired, under the influence of alcohol or prescription drugs.

**Any person not directly operating** the machine should stay away from the equipment as not to distract the operator or accidentally move control element. Avoid talking to the operator while the equipment is in operation.

**During any set-up adjustment**, maintenance work or cleaning of the machine etc., it is imperative that the main electrical and pneumatic power supply be disconnected to avoid accidental operation and resultant injury. This is particularly important when more than one person is involved in such task.




**DANGER ! Do NOT ENTER WITHIN THE ROTATING INDEX TABLE AREA UNLESS ALL SAFETY PRECAUTIONS HAVE BEEN OBSERVED.**

## 1.3- SAFETY DEVICES INSTALLED ON THE MACHINE :

The machine is equipped with different safety devices:


**On the operator control:**

- 1- Emergency stop
- 2- Red press button "Control off". When pressed, the control power supply is deactivated.




### On the base of the machine:

- The main switch enables to cut the power supply of the machine. It cannot be used as emergency stop, but before any electrical, mechanical or pneumatic repair, before opening any cover, the mains power supply of the machine should be turned off by turning the mains switch to the position "0".



Main switch

### Around the machine:




Each print station is equipped of one or two safety bars. Before entering into the machine rotating indexing table area, at least one of the safety bars has to be open. When one or more safety bar are open, the safety modus is activated, no rotation movement is possible.



**CAUTION:** Before any maintenance or cleaning of the machine, turn the main switch off instead of opening a safety bar.

## 1.4- Check the different safety devices:

Once a month, the function integrity of all the safety devices should be check. Proceed as follows:




### **Emergency stop:**

**Action:** Press on the emergency stop button while the machine is running in automatic mode.

**Effect:** The machine stops instantly, on the operator interface the following warning appears: « Emergency stop activated »

**Restart:** Unlock the emergency stop by turning it to the left. The warning on the interface will disappear, drive the machine to its start position ( See page 11)




### **Control OFF press button :**

**Action :** press on the "Control off" press button while machine is running in automatic

**Effect :** the main control power supply is deactivated, the machine stops instantly, the operator interface is switched off.

**Restart:** press on the button "Control ON" and start the machine as depicted on page 11.



### **Each printing station is equipped with at least one safety bar.**

**Action:** Activate successively all safety swivelling bars.

**Effect:** The machine stops instantly, respectively, the red lamp on the print station actually open will shine and the following warning will appear on the operator interface: "Safety door open "

**Restart:** close the safety bar, press the RESET button on the operator interface or on one of the « SCHENK » logo situated on each control pad in front of each print station.




**-On the floor in front of the machine is a STOP foot pedal:**

**Action:** While the machine is running in automatic mode, press once on the stop pedal.

**Effect:** The machine stops instantly..

**Restart :** Press on the start pedal or on the white arrow on the operator interface.



**-On each printing station is a small control pad: the pad with a red triangular symbol:**

**Action:** While the machine is running in automatic mode, press on the pad with a red triangular symbol situated on each control pad on each print station.

**Effect :** The machine stops at the end of the actual printing cycle.

**Restart:** Press once again on the logo SCHENK pad and red triangular symbol at the same time, the machine will turn one segment and start straight away in automatic.


SCHENK  
+  
RED BUTTON



**If during the check up, one of the safety devices do not react the way described on the above description, it is important to proceed as follow:**

- Stop the machine and turn mains power supply switch OFF.
- Lock mains power supply switch
- Tag a shield on the disconnect switch, stating that the power supply should not be switched ON, under no circumstance, to avoid an accidental reactivation of the switch.
- Contact as soon as possible the WALZ GmbH service department.

## **1.5 – Informal safety measures:**



The operating guide has to stay on site where the machine is installed.

Attached to it should be the general and local rules of accident prevention and environmental protection. These rules have to be respected and applied.

## **1.6 - Operator training**

Only the machine operator trained to use the machine is allowed to manipulate the operator interface, set the printing parameters, use the manual and automatic functions and print on the machine.

The competence of the machine operator has to be defined clearly by the employer. Any employee not completely trained should not be allowed to work on the machine without the supervision of an experienced operator.

## **1.7 – Controls and machine settings**

Only a fully qualified machine operator should be allowed to use the different machine functions and/ or change any production parameters using the operator interface.

## **1.8 – Safety measures during production:**

The running of the machine is authorised only when all the safety devices are in perfect working condition.

Before starting the machine in automatic mode, be sure that no object, piece of equipment are in contact with any moving part. Before starting the machine in automatic mode be sure that no person is in contact with any moving part of the machine, that no one is in the rotating table area, that no one is actually adjusting any part on the machine or under the printing station.

Inspect daily the machine for any damages or loose parts, check visually all safety devices.

## **1.9 Risks due to the electrical power supply**

Any installation or repair or maintenance work, on any electrical parts of the machine has to be carried out exclusively by a qualified electrician.

The access to any electrical cabinet on the machine is authorised exclusively to a qualified electrician.

Before starting any repair or installation on the electric parts of the machine, switch main switch OFF and/or disconnect the plug of the socket.

## 1.10 Special danger areas

The Schenk screen printing machines have been designed and manufactured according to the latest state-of-the-art and knowledge. However, there are still some risks and areas of danger, which cannot be totally ruled out.



### **Danger**

Do not duck under the safety bar to get to the machine. There is a risk of serious and even fatal injury when the machine rotates.




### **Caution**

Clamping levers and screws need to be released and fixed for setting work. Make sure you use the suitable tools and never use force, you could injure yourself or damage the machine.

## 1.11 – Transformations, changes on the machine


It is no allowed to do any modification on the machine without the written consent of the company Heinz Walz GmbH. This interdiction includes any welding on any part of the machine.




### **Note**

For any repair use only original spare parts, particularly for any electrical or mechanical parts of the safety devices. The use of non original or non compatible parts will not guaranty an optimal function.

# 1- START THE MACHINE




Turn the main pneumatic supply ON, by rotating the manual valve from the vertical position to the horizontal position. Check the air pressure, the working pressure value is of 8 bars.




1. Turn the main switch to the position « I »
2. Check that the emergency stop is not activated, if it is the case, turn it to the left to unlock it.
3. Press the button "Control ON"
4. Now the PLC is on. The PLC will take one minute to load its program; the operator interface is on, but not in function until the PLC program is fully loaded.

Main switch




Emergency stop

Control on



5. When the PLC's program is loaded, the operator interface is in function, the red lamp on top of the machine shines. On the operator interface this display appears.

6. Press on the pad "**main menu**"




7. In the **Main Menu** display press on the blinking warning to access the warning/ error menu.

**Blinking warning symbol in case of error or warning**

8. Check the alarms, the following warning is displayed:

«**Lift/ Rotation not in position.** » meaning that the two axis are not in starting position.

In case the warning "**safety door open**" is displayed, check and close the safety bar and press on the **Reset** button.




9. Press on "**START**"

The lift axis will run in starting position, then the rotating table.


Once the axes are in position, the machine will stop. No warning or alarm should appear on the display.

## "Main Menu display" functions:




- 1- Access to **“warnings and errors menu”**.
- 2- Description of the latest warning or error
- 3- Access to overview display
- 4- Actual piece count
- 5- Access to **“adjustment”** menu
- 6- Access to **“Manual functions”** menu
- 7- Activation of the **foot pedal**. By activating this function the machine will start only by pressing the start foot pedal. One pedal impulse/ one print cycle. Deactivation possible only when in stop status.
- 8- Activation of the **“unload function”**. By pressing this pad, the machine will start deactivate one station after another until stop.
- 9- Identification number of the station. In this case the station number two is free.
- 10- Identification number of the station. In this case the station number one is a printing station activated in print modus.
- 11- Loading pallet
- 12- Unloading pallet
- 13- Access to the stations configuration menu. Pressing this circle enables the setting of parameters and configuration of each individual station.
- 14- Activation of the **“Load function”**. By pressing this pad, the machine will activate one station after another.
- 15- Stop. By pressing this pad, the machine will stop until the actual printing cycle is over
- 16- Start. By pressing this pad, the machine will start printing
- 17- Access to the automatic menu.

## « Adjustments » menu:



You can access the menu "Adjustment" by pressing one of these pads.




- 1- Return to main overview menu.
- 2- Return to previous page
- 3- Go to next page.
- 4- Reset to zero the lot size amount.
- 5- When the Mixing program is active: we can set here the amount of full rotations comprised in one Mixing production cycle. It can be 2, 3 or 4.
- 6- Activation of the "Mixing function"
- 7- Activation of the "Return" function.
- 8- When this function is activated, **only every second pallet will be printed**. This function enables the use of big pallets fixed on every second pallet arm, and the use of all printing heads and flash cure necessary.

- 9- When this function is active, all print heads set with program 2 will always flood as last squeegee movement.
- 10- The movement flood and print will be interchanged.
- 11- When this function is active, the pallet will only turn, without printing, enabling a **warm up** of the pallet surface. By pressing the "Load function" the machine will start printing
- 12- **Half index** function
- 13- **Double index** function
- 14- Setting of the **delay** time between printing cycle
- 15- Setting of a **lot size**
- 16- Setting of the **Lift Off Contact**
- 17- Setting of **Up and Down Lift speed**
- 18- Setting of one of the three **rotation speed**


**Next page on the "Machine settings" menu:**

**MIXING:**




When the MIXING function is active, the following displays will be used to configure which stations will be printing in the successive rotations.

Here we can set the amount of full rotation needed




On these menus we can activate the stations needed for each rotation.

Here we set the stations for the first and second rotation



Here we set the stations for the third and fourth rotation


Next page on the "Machine settings" menu:



- 1- Return to main overview menu.
- 2- Return to previous page
- 3- Go to next page.
- 4- Reset Lot size to zero
- 5- **Ink recovery function:** this function enables the squeegees to stop every "n" T-shirt few centimetres further on the screen to recover the ink deposit accumulated there during the print process.
- 6- Production rate information
- 7- When the machine is set in half index, the waiting time of the half index position can be set independently of the waiting time set for the printing process
- 8- When printing stations are set in program number 3, we can set the off contact height in this menu, enabling a minimum adjustment of the lift up movement.
- 9- Delay of the squeegees horizontal movement in relation to the up/down movement
- 10- Setting of lot sizes
- 11- When a flash cure or a flocking device is attached to the machine, we can here decide if the communication between the two devices will be done when the T-shirt is near the flash cure/ flock or far from the devices.

INK RECOVERY FUNCTION:

This function enables the squeegees to stop every "n" T-shirt few centimetres further on the screen. to recover the ink deposit accumulated there during the print process.




- 1- Set the frequency to which the function will be active. For example set to 25, then every 25 prints, the squeegee will remove the ink
- 2- Set the stop delay in ms for inner squeegee movement
- 3- Set the stop delay in ms for the outer squeegee movement


For example, for a speed squeegee movement set to 50% (value of the potentiometer fitted at the front of the printing station), and a setting of 100ms, the squeegee will overshoot 3cm.

## 2- PRINTING STATIONS CONFIGURATION


Each station can be individually configured. Each station can be activated or deactivated; each station can be set with a different printing programme and a different stroke amount. Proceed as follow:



By pressing the middle of the circle the following menu will appear.



Changing a station configuration and/or program is **only possible in automatic stop or manual status**



Return to main overview menu.

- 1- Return to previous page
- 2- **Replay function:** when set, this function enables "n" times the pallet to return to this station to be reprinted.
- 3- Amount of squeegee strokes and print program choice
- 4- Reset all station: All stations status will be reset to zero.
- 5- Activate or deactivate the station as print station, flock unit or flash cure
- 6- Scroll station number

## The station can be configured as follow:

**Prog.1:** Print station activated. Following printing cycles: Lift down, 1 to 9 squeegees strokes (**adjustable value**), lift up, rotation.

**Prog.2:** Print station activated. Following printing cycles: First 1 flood squeegee stroke, lift down, 1/ 3/ 5/ 7/ 9 squeegee strokes (Adjustable amount, **tip always an uneven amount** of strokes. Lift up and during rotation 1 flood stroke.

**Prog.3:** Print station activated. Following printing cycles: lift is in upper position, one flood stroke, lift down, one print stroke and then lift up. This cycle can be repeated up to nine times.

**Prog.4:** Is like program #2 but the flood strokes amount can be set by pressing on + and - next to **the pink square**.

**Flock:** Station activated with a flocking device.


**Deactivated:** Station deactivated .

When all the stations have been configured, press "PRINT" to activate the automatic printing function and then press start.

### 3- Hand mode function:

The different movements of the machine can be activated separately in hand modus. This function is particularly useful during the adjustment of the screens and the print trials. There are two ways to activate the different hand modus function:

- **From the small control pad in front of each printing station.**



The hand functions are possible from the control pads on each station, only when the print function is deactivated and the bleu hand is visible.

#### Six functions are possible from the control pads:

- By pressing the button , the frame locking pneumatic cylinder will be activated, the red LED is ON when the frame is not locked.

- By pressing the button , the squeegee carrier pneumatic cylinder will move back and forth, one impulse, one movement.

- By pressing the buttons  and  at the same time the lift will move up and down, one impulse, one movement.

- By pressing the buttons  and  at the same time, the table will rotate to the **left** from one printing station to the next one.

- By pressing the buttons  and  at the same time, the table will turn into cleaning position, 1/2 index.


- By pressing the buttons  and  at the same time, the table will rotate to the **right** from one printing station to the next one.

#### Note





When the hand modus functions are activated and controlled from the touch screen, the control pads on each printing station are deactivated. When the hand modus functions are activated and controlled from the print stations, the touch screen is deactivated


**Seven hand functions are possible from the touch screen:**



By pressing the button with a hand symbol the following menu will appear



- 1- Scroll and choose the station you want to activate.
- 2- Squeegee UP DOWN
- 3- Squeegee back and forth
- 4- Screen lock / unlock




- 1- By pressing this button, the pallet #1 will come back in front position, reference position.
- 2- Pallet turn left
- 3- Lift up and down
- 4- Pallet turn right
- 5- All squeegees inside
- 6- All squeegees outside
- 7- Actual pallet number in loading position

## 4- Maintenance warning:

Every a preset time of production, the machine will warn you that it is time to lubricate the two axes: The rotating axis and the lift axis.


On the display the following warning will appear: **MAINTENANCE: Lubricate Lift/Rotation axis.**

The red lamp will blink to signal the warning. The machine will keep running.



Proceed as follow to lubricate the machine and reset the maintenance counter:

- 1- Stop the machine
- 2 - Exit the printing program
- 3- Open a security door






Your machine is delivered with an action grease pump:

One to two grease injections per greasing point every 80 hours of production is enough to guaranty the good maintenance of the lift axis and lift gear.


+

**V2002 EX Lift Device Lubrication**




**Note**  
If your machine is V2002EX, EX meaning that the lift is powered with an eccentrically Lifting device, you will find on the right hand side of the machine four lubricating points. Using the provided grease pump lubricate the four points.

To reset the maintenance timer to zero proceed as follow:




- Stay **out** of the print mode, press on this symbol. This symbols appears only when it is time to lubricate the axis



- Press on the button "Maintenance Reset". The countdown timer will return to zero.





# SECURITY SCANNER OPTION:



The scanner has to be connected on the Module A3, Input 9.  
 The scanner can be activated in two different manners:


1-When somebody enters the scanner security area, the rotation is stopped, the machine keeps printing and the lift function still operating until the print process is finished. The machine starts **only** after having press the start button on the touch screen or press the Start foot pedal. **This function is active only when the delay timer is set to zero or a positive value (i.e. 3 seconds)**



2-

When somebody enters the scanner security area, the rotation is stopped, the machine keeps printing and the lift function still operating until the print process is finished. Once the person leaves the secured area, the machine will start automatically without pressing the start pedal or start button, and will turn one segment. Every time a person enters and leaves the area, the machine will turn only one segment and will stop at the end of the printing process. **This function is active only when the delay timer is set to a negative value (i.e. -1 second)**

## AUXILIARY UNITS INTERCONNECTION:



Auxiliary units like Flash Cures, Flocking boxes, Humidifiers, Coolers, Digital printer, can be interconnected to the printing machine enabling synchronization between both machines.

The OUTPUT X1.5 sends the signal START, 24V DC

The INPUT X2.5 receives the signal FINISH.





**IMPORTANT:** The 24V DC for input X2.5 has to be taken from our machine. No external voltage is allowed into the input!

The form of the signal can be selected by first activating the station as flash cure, independently of the type of unit, then by selecting a number from 1 to 4 corresponding to the wished signal.

Following are the actual possibilities to communicate between machines:

1. The screen printing machine sends a signal starts in the form of a 24V output. This signal stays high until the Flash cure sends a finished signal.
2. The screen printing machine sends a signal starts in the form of a 24V output. This signal stays high. This signal triggers the timer countdown of the flash cure and the flash cure sends a signal back to the printing machine which signal will stay high until the time is up. Then the start signal of the printing machine falls low.
3. Set the delay timer to a wished value. The screen printing machine sends a signal which stays high the time set in the delay menu.
4. The Screen Printing machine sends a one second impulse every time the machine is in position and ready.




Flash cures and any accessories attached to the printing machine can be interconnected to receive START signals and send back FINISH signals. This communication can be set to assess WHEN the signal has to be sent and HOW this communication has to be done:

if the attached device is a Flash cure, activate the button flash cure. (1)


Now with the button Apart (2) you can choose to activate the flash cure far from the substrate or near the substrate.

With the button Program (3) you can choose the form of the communicating signal adapted to your flash cure.(see next page)






if the attached device is a Flocking box or a Digital printer, activate the button Flock. (1)

With the button Program (3) you can choose the form of the communicating signal adapted to your flash cure.(see next page)



The communication between the printing machine and attached device can be done of four different ways. You can choose the communication way by pressing the "Programme" button



## 7- Alarm- Message listing

The following alarms and errors messages may appear on the display during operation.

CONTROL POWER SUPPLY IS OFF: Press the button "Control ON". The machine's control power supply will be activated.

EMERGENCY STOP IS ON: Emergency button is on. Turn it to the left to unlock it, then the button "control on".

SECURITY BARRIER IS OPEN: At least one security barrier is open. You can localise it by checking which red light on the print station is on .

MAINTENANCE: GREASE AXIS: Every 35 hours this warning will appear signalling that it is time to lubricate the two axes, rotation and lift. Reset the warning as described on the page 23.

LIFT NOT IN START POSITION: The lift is not in its upper position.

Check the upper lift sensor.

Check if a warning code appears on the servo controller display (See page 24 and 25)

LIFT TIMEOUT: NOT IN UPPER POSITION: The lift is not in its upper position.

Check the upper lift sensor..

Check if a warning code appears on the servo controller display (See page 24 and 25)

LIFT TIMEOUT: NOT IN LOWER POSITION: The lift is not in its lower position.

Check the lower lift sensor..

Check if a warning code appears on the servo controller display (See page 24 and 25)

ROTATION AXIS IS OFF OR PROFIBUS ERROR: The servo controller A1 is off, or 24V are missing on connection X2 . (24v and GND)

If the error persists check the Profibus cable and connector.

LIFT AXIS IS OFF OR PROFIBUS ERROR: The servo controller A2 is off, or 24V are missing on connection X2 . (24v and GND)

If the error persists check the Profibus cable and connector.

STOKES AMOUNT MUST BE UNEVEN: In print program 2, the set amount of strokes has to be uneven

FRAME NOT CLAMPED STATION : The frame clamping device of the mentioned station is open. Close the clamping device.

TIME OUT SQUEEGEE STATION : The squeegee of the mentioned station has not reach its position. Check the space between sensor and activating plate. If the squeegees are electrically driven, check if the speed adjustment potentiometer is not at its lowest value.

## 8- Faults/ Events warnings code STOEBER POSIDYN SDS 4000 Servo controller.

When faults occur, the inverter is no longer able to control the drive and is disabled.  
An entry is made in the fault memory.  
(E40/E41), and relay 1 (ready for operation) releases.

31: Short/ground	The hardware over current switch-off is active. Motor requires too much current from the inverter (e.g., inter-winding fault or overload).
32: Short/gr. int.	When the inverter is enabled, an internal check is performed. A short circuit triggers a fault. • An internal device fault has occurred (e.g., IGBT modules are defective)
33: Overcurrent	Acceleration times too short. Lengthen ramps in group <b>D</b> . • Check torque limits <b>C03 / C04</b> . - Which torque limits are in effect? See chapter 9.2. - Reduce torque limits <b>C03/C04</b> set to maximum value by approx. 10 %. • Optimize parameter <b>C30</b> (ratio of the moments of inertia). • With vector control ( <b>B20=2</b> ): encoder not connected correctly
34: Hardw. fault	The non-volatile data memory is defective or software version is time-limited.
35: Watchdog	Monitors the load and functions of the microprocessor
36: High voltage	DC-link voltage too high. . Power too high . Reverse powering of the drive while braking (no brake resistor connected, brake chopper defective, brake chopper deactivated with A20).
37: n-feedback	Resolver: Wire break or signal level too low Fault can only be acknowledged by turning 24 V off and on! Sin/cos absolute-value encoder: . During device startup - Communication to the device is faulty. - Absolute-value encoder unknown - Communication protocol unknown (neither EnDat nor HiperFace) . During operation - Wire break or signal level too low - Change in B26
38: tempDev.sens	The heat dissipater temperature is over the limit value. Cf. E25. . Temperature of environment/switching cabinet is too high.
39: TempDev.i2t	The inverter limits the output current to 99% of the nominal current. The i2t model calculated for the inverter has reached 100% of the thermal load. . Inverter is overloaded. (Inverter too small). . Temperature of the environment/switching cabinet is too high. . Closed brake . Motor connected incorrectly . Resolver connected incorrectly

40: Invalid data	The data in non-volatile memory are incomplete. Reset non-volatile memory with "A00save values." This loads the default values.
41: Temp.motorTMP	Excessive temperature indicated by the motor temperature sensor. . Motor is overloaded. Use external ventilation. . Temperature sensor not connected (X40.2 to X40.6)
42: Temp.brakeRes	The i2t model calculated for the brake resistor has reached 100% of the thermal load The i2t model calculated for the brake resistor has reached 100% of the thermal load . A20 programmed incorrectly . Permissible power loss of brake resistance is too high. . With internal brake resistance: No jumper on X12. . With external brake resistance: Brake resistor not connected.
44: Ext.fault	Fault triggered by BE
45: OTempMot.i2t .	Motor overloaded . Cooling insufficient
46: Low voltage	DC-link voltage is below the limit value set in A35. . Drops in the power supply . Acceleration times are too short (ramps, D ..).
47: Device overl.	The maximum torque has been exceeded. The permissible torque is limited by parameters C03 and C04 and the possible torque limitation via analog input.
48: Accel. overl.	Same as "47:Device overload" except for an acceleration procedure. M-Max 2 (C04) is permitted for the acceleration procedure with "cycle characteristic" startup (C20=2).
49: Decel. overl	Same as "47:Device overload" except for a deceleration procedure
50: Operat. area	The operating area defined under C41 to C46 has been exited.
51: Refused	Only for positioning (C60=2). Posi.start or posi.step was not accepted. . Destination position is located outside software limit switches. . In non-referenced status (I86=0), no absolute positions (e.g., J11=1) are traveled to. . The direction of rotation in the current process block is not the same as the permissible direction I04.
52: Communication	. Fault during communication between inverter and FDS Tool during remote control via PC . Communication fault during fieldbus operation
53: Stop input	A limit switch connected via a BE input or monitored via fieldbus has been triggered. During referencing at the limit switch (I30=1), a reversal of the limit switches will cause a fault.
54: Follow. error	The maximum following error (i.e., deviation between actual position and reference value position) permitted by I21 has been exceeded. . Motor overload, too much acceleration or blockage . Kv-factor I20 too small, speed feed forward I25 too small
55: OptionBoard	. When option board SEA-4000 is used, the external 24 V voltage is not present or the card is defective. No fault if enable is deactivated.

	. No option card found
56: Overspeed	Actual speed exceeds n-Max by more than 15%.

## **10- Disclaimer of warranty and limitation of liability**

### **Installation:**

We will furnish one (or more) factory technician(s) to assist and supervise the machine installation.

Buyer will provide additional labour and handling equipment.

Installation of all utilities (Power supply and compressed air) are at the Buyer's expense. Buyer must prepare prior of WALZ GmbH technician arrival all electrical, air and gas line (When applicable).

Failure to ready all necessary utilities prior to the arrival of WALZ GmbH technician may result in penalty for each delayed installation day.

All service technician travel, lodging, and sustenance costs remain solely the customer's responsibility unless otherwise stated in the order confirmation.

### **Limited Warranty:**

Machinery manufactured and/or sold by WALZ GmbH is warranted against defect in workmanship and materials for a period of one year. All warranties initiate from date of shipment.

Replacement parts are covered for the term of the machinery warranty period.

Any part found by WALZ GmbH to be defective in material or workmanship within the stated warranty period will be replaced or repaired at WALZ GmbH without charge when returned, freight prepaid, in within of the warranty period. Written authorisation must be obtained from WALZ GmbH before any part will be accepted.

**WALZ GmbH does not warrant failure of parts or component resulting from misuse or lack of proper maintenance.**

Any service work performed on this machine by persons other than WALZ GmbH certified service technician or persons specifically authorised by WALZ GmbH shall nullify this warranty.

This warranty is applicable to original machinery owner only and cannot be transferred to subsequent machinery owners.



Schaltplan / Electro Diagram

# Easy - Spider EX - V 2002 EX

Schleicher PLC XCX300 / XCX400




Heinz Walz GmbH  
Maybachstr. 3  
72793 Pfullingen  
Germany



Tel.0049-7121 9298-0  
info@walz-gmbh.de  
www.walz-gmbh.de

Schaltplan Nr.18.39.03



# Einspeisung und Versorgung


Infeed and supply



Heinz Walz GmbH  
 Maybachstr. 3  
 72793 Pfullingen  
 Germany

Datum	02.10.18
Nr.	

Page	1
of	19



○ oben/up  
 ● unten/down


# EIN / AUS - NOT AUS

## Emergency Stop

**Walz**  
 Heinz Walz GmbH  
 Maybachstr. 3  
 72793 Pfullingen  
 Germany

info@walz-gmbh.de  
 www.walz-gmbh.de  
 Tel.0049-7121 9298-0

Datum	02.10.18
Nr.	



Heinz Walz GmbH  
Maybachstr. 3  
72793 Pfullingen  
Germany


info@walz-gmbh.de  
www.walz-gmbh.de  
Tel.0049-7121 9298-0


# SPS XCX 300 / Touchscreen

Datum 02.10.18  
Nr.

Page 3.1  
of 16

1 2 3 4 5 6 7 8








# XCX300 IO's GLOBAL A2 / A3

  
**Walz**  
 Heinz Walz GmbH  
 Maybachstr. 3  
 72793 Pfullingen  
 Germany

info@walz-gmbh.de  
 www.walz-gmbh.de  
 Tel.0049-7121 9298-0









# FU Raket Emerson

**Walz**  
Heinz Walz GmbH  
Maybachstr. 3  
72793 Pfullingen  
Germany

info@walz-gmbh.de  
www.walz-gmbh.de  
Tel.0049-7121 9298-0





Datum 09.10.18

Nr.

# Spider Drehen/Rotation




Heinz Walz GmbH  
 Maybachstr. 3  
 72793 Prüllingen  
 Germany

info@walz-gmbh.de  
 www.walz-gmbh.de  
 Tel.0049-7121 9298-0

Page 8

of 16



# Spider EX Heben/Lift


Datum 09.10.18  
 Nr. \_\_\_\_\_

Heinz Walz GmbH  
 Maybachstr. 3  
 72793 Prüllingen  
 Germany



Tel.0049-7121 9298-0  
 info@walz-gmbh.de  
 www.walz-gmbh.de






# V2002 EX Heben/Lift

	1	2	3	4	5	6	7	8	
	print station								
	<b>Druckwerk 1</b>		<b>Druckwerk 2</b>		<b>Druckwerk 3</b>		<b>Druckwerk 4</b>		<b>Druckwerk 5</b>
	<b>Druckwerk 6</b>								
A	Adresse		Adresse		Adresse		Adresse		Adresse
B	1		1		1		1		1
C	2		2		2		2		2
	3		3		3		3		3
	4		4		4		4		4
	5		5		5		5		5
	6		6		6		6		6
	7		7		7		7		7
	8		8		8		8		8
	9		9		9		9		9
	10		10		10		10		10
	ON								
	OFF								
	Adr 1								
	Adr 2								
	Adr 4								
	Adr 8								
	Adr 16								
	Adr 32								
	Adr 64								
	Beaud 1								
	Beaud 2								
	Beaud 3								
	ON								
	OFF								
	11		12		13		14		15
	16		17		18		19		20
	21		22		23		24		25
	26		27		28		29		30
	31		32		33		34		35
	36		37		38		39		40
	41		42		43		44		45
	46		47		48		49		50
	51		52		53		54		55
	56		57		58		59		60
	61		62		63		64		65
	66		67		68		69		70
	71		72		73		74		75
	76		77		78		79		80
	81		82		83		84		85
	86		87		88		89		90
	91		92		93		94		95
	96		97		98		99		100
	101		102		103		104		105
	106		107		108		109		110
	111		112		113		114		115
	116		117		118		119		120
	121		122		123		124		125
	126		127		128		129		130
	131		132		133		134		135
	136		137		138		139		140
	141		142		143		144		145
	146		147		148		149		150
	151		152		153		154		155
	156		157		158		159		160
	161		162		163		164		165
	166		167		168		169		170
	171		172		173		174		175
	176		177		178		179		180
	181		182		183		184		185
	186		187		188		189		190
	191		192		193		194		195
	196		197		198		199		200
	201		202		203		204		205
	206		207		208		209		210
	211		212		213		214		215
	216		217		218		219		220
	221		222		223		224		225
	226		227		228		229		230
	231		232		233		234		235
	236		237		238		239		240
	241		242		243		244		245
	246		247		248		249		250
	251		252		253		254		255
	256		257		258		259		260
	261		262		263		264		265
	266		267		268		269		270
	271		272		273		274		275
	276		277		278		279		280
	281		282		283		284		285
	286		287		288		289		290
	291		292		293		294		295
	296		297		298		299		300
	301		302		303		304		305
	306		307		308		309		310
	311		312		313		314		315
	316		317		318		319		320
	321		322		323		324		325
	326		327		328		329		330
	331		332		333		334		335
	336		337		338		339		340
	341		342		343		344		345
	346		347		348		349		350
	351		352		353		354		355
	356		357		358		359		360
	361		362		363		364		365
	366		367		368		369		370
	371		372		373		374		375
	376		377		378		379		380
	381		382		383		384		385
	386		387		388		389		390
	391		392		393		394		395
	396		397		398		399		400
	401		402		403		404		405
	406		407		408		409		410
	411		412		413		414		415
	416		417		418		419		420
	421		422		423		424		425
	426		427		428		429		430
	431		432		433		434		435
	436		437		438		439		440
	441		442		443		444		445
	446		447		448		449		450
	451		452		453		454		455
	456		457		458		459		460
	461		462		463		464		465
	466		467		468		469		470
	471		472		473		474		475
	476		477		478		479		480
	481		482		483		484		485
	486		487		488		489		490
	491		492		493		494		495
	496		497		498		499		500
	501		502		503		504		505
	506		507		508		509		510
	511		512		513		514		515
	516		517		518		519		520
	521		522		523		524		525
	526		527		528		529		530
	531		532		533		534		535
	536		537		538		539		540
	541		542		543		544		545
	546		547		548		549		550
	551		552		553		554		555
	556		557		558		559		560
	561		562		563		564		565
	566		567		568		569		570
	571		572		573		574		575
	576		577		578		579		580
	581		582		583		584		585
	586		587		588		589		590
	591		592		593		594		595
	596		597		598		599		600
	601		602		603		604		605
	606		607		608		609		610
	611		612		613		614		615
	616		617		618		619		620
	621		622		623		624		625
	626		627		628		629		630
	631		632		633		634		635
	636		637		638		639		640
	641		642		643		644		645
	646		647		648		649		650
	651		652		653		654		655
	656		657		658		659		660
	661		662		663		664		665
	666		667		668		669		670
	671		672		673		674		675
	676		677		678		679		680
	681		682		683		684		685
	686		687		688		689		690
	691		692		693		694		695
	696		697		698		699		700
	701		702		703		704		705
	706		707		708		709		710
	711		712		713		714		715
	716		717		718		719		720
	721		722		723		724		725
	726		727		728		729		730
	731		732		733		734		735
	736		737		738		739		740
	741		742		743		744		745
	746		747		748		749		750
	751		752		753		754		755
	756		757		758		759		760
	761		762		763		764		765
	766		767		768		769		770
	771		772		773</				



**Encoder HTL FDS 5000**

Motor	Signal	Wires colors Aderfarben		Sub-D-15 x4
		Motorintern	Encoder	
1	B-	PK	YE	9
2				
3	N	RD	PK	3
4	N-	BK	GY	10
5	A	BN	BN	6
6	A-	GN	WH	11
7				
8	B	GY	GN	1
9				
10	GND	WH	BU	2
11				
12	U <sub>2</sub>	BN	RD	4
Gehäuse	Schirm			




**Encoder SSI MDS 5000**

Signal	Motor	Wires colors Aderfarben		Sub-D-15 x4
		Farbe	Pin	
Data +	6	weiß ws	5	
Data -	5	braun br	13	
Clock +	1	gelb ye	8	
Clock -	8	grün gn	15	
Up +	12	rot rd	4	
Up Sense <sup>a)</sup>	2	rosa pk	12	
0 V GND <sup>a)</sup>	10	blau bu	2	


**CAN X200**

Pin	Bezeichnung	Funktion
1	nc	—
2	CAN-low	CAN-Low Leitung
3	GND	Signal Ground
4	nc	—
5	nc	—
6	CAN-High	CAN-Low Leitung Intern mit Pin 2 verbunden
7	CAN-high	CAN-High Leitung
8	nc	—
9	CAN-high	CAN-High Leitung Intern mit Pin 7 verbunden



schwarz	sw	BK
braun	br	BN
rot	rt	RD
orange	or	OG
gelb	ge	YE
grün	gn	GN
blau	bl	BU
violett	vi	VT
grau	gr	GY
weiß	ws	WH
rosa	rs	PK
türkis	tk	TQ
grün-gelb	gng	GNYE

**Positool / FDS Tool Servicekabel**



Datum 08.10.15

Nr.

**Kabel/Steckverbinder**  
Wire/plugs

**Walz**  
Heinz Walz GmbH  
Maybachstr. 3  
72793 Pfullingen  
Germany

info@walz-gmbh.de  
www.walz-gmbh.de  
Tel.0049-7121 9298-0

Page 14

of 16

