

**trotec**

# Speedy 360

Operating manual



**8085**

BA 8085\_4.12\_DE (12/2023)  
ENGLISH

/ SETTING NEW STANDARDS

**Trotec Laser GmbH**

+43 7242 239-7070  
service-at@troteclaser.com

**Trotec Laser Canada**

+1 800 663 1149-902  
techsupport@troteclaser.ca

**Trotec Laser Deutschland GmbH**

+49 89 322 99 65-13  
service-de@troteclaser.com

**Trotec Laser UK**

+44 0191 4188 110  
service-uk@troteclaser.com

**High Speed Laser Systems S. de R.L. de C.V.**

+52 55 5351-7252  
mexico@troteclaser.com

**Trotec Laser Inc.**

+1 866 226 8505, Option 2  
support@troteclaser.com

**Trotec Laser Pty Ltd**

+61 26413-5904  
service@troteclaser.com.au

**Trotec Laser AG**

+41 32387-1611  
service-ch@troteclaser.com  
suisse@troteclaser.com

**Trotec Laser España**

+34 93 102 50 50  
soporte@troteclaser.com

**Trotec Laser Srl**

+39 02 9475 5447  
supporto.tecnico@troteclaser.com

**Trotec Laser B.V.**

+31 850 70 51 55  
support@troteclaser.nl

**Rubber Stamp & Engraving**

+27 875 509-335  
support@trodat.co.za

**Trotec Laser België  
Trotec Laser Belgique**

+31 850 70 51 55  
support@troteclaser.nl

**Trotec Laser GmbH**

+86 189 500 735 62  
china@troteclaser.com

**Trotec Laser France SAS**

+33 1 72 62 20 94  
techsupport.fr@troteclaser.com

**Trotec Laser Japan Corporation**

Tokyo: +81 42 313 0740  
Osaka: +81 6 6180 2200  
service-jp@troteclaser.com

**Trodat Polska Sp. z o.o.**

+48 22 339 35 39  
serwis\_pl@trodat.net

**Trotec Laser (XIAMEN) CO., LTD.**

#5 GuAn Road South, MaXiang  
Town  
XiangAn District, XiaMen, China

---

**Trotec Laser GmbH**

Freilingerstraße 99  
4614 Marchtrenk, Austria

**General contact to Technical Support:**

Tel.: +43 7242 239-7000

E-mail: [techsupport@troteclaser.com](mailto:techsupport@troteclaser.com)

**[WWW.TROTECLASER.COM](http://WWW.TROTECLASER.COM)**

---

Technical Changes	Technical specifications are subject to change without notice. Trotec Laser GmbH reserves the right to improve or modify any of the products without prior notice.
© Copyright	This documentation with all illustrations is intellectual property of Trotec Laser GmbH. The entire documentation is given to the user for personal use only. Reproduction, translation or any distribution to third parties is not permitted without the prior consent of Trotec Laser GmbH. Any breach of law will be prosecuted.

---

 Content

<b>1</b>	<b>General Information.....</b>	<b>8</b>
1.1	Information about this manual.....	8
1.2	Explanation of symbols.....	8
1.3	Liability and warranty.....	9
1.4	Scope of delivery (standard configuration).....	10
1.4.1	Accessory box.....	10
1.5	Type plate.....	11
<b>2</b>	<b>Safety.....</b>	<b>12</b>
2.1	General safety notes.....	12
2.1.1	Intended use.....	12
2.1.2	Improper use.....	13
2.1.3	Residual risk.....	13
2.1.4	Machine modification.....	13
2.1.5	Operating modes.....	13
2.1.6	Applicable safety regulations.....	14
2.2	Areas of responsibility.....	16
2.2.1	Responsibilities of the operator.....	16
2.2.2	Responsibilities of the operating personnel.....	17
2.3	Requirements for operating an service personnel.....	18
2.4	Warning and information labels.....	19
2.5	Safety devices.....	20
2.6	Technical protective measures.....	20
2.6.1	Main switch.....	20
2.6.2	Key switch.....	20
2.6.3	Emergency stop button.....	20
2.6.4	Interlock safety switches.....	21
2.6.5	Acrylic top lid.....	21
2.6.6	Side cover.....	21
2.6.7	Temperature sensor.....	21
2.6.8	In case of safety device malfunction.....	21
2.7	Secondary (indirect) hazards.....	22
2.7.1	Fire hazard.....	22
2.7.2	Gases, fumes and dust.....	22
2.7.3	Hazards due to damaged optics.....	23
2.7.4	Protective measures for damaged optics.....	23
2.8	In case of emergency.....	25

<b>3</b>	<b>Technical Data.....</b>	<b>27</b>
3.1	Dimensions and weight.....	27
3.2	Network connection.....	28
3.3	Computer connection.....	28
3.4	Requirements for the electrical connections of the machine.....	29
3.5	Exhaust system requirements.....	30
3.6	Materials list.....	31
<b>4</b>	<b>Machine overview.....</b>	<b>35</b>
4.1	Anlagenübersicht.....	35
4.2	Ruby server status LED.....	37
4.3	Front door.....	38
4.4	Tables (multifunctional table concept).....	38
4.5	Lens(es).....	40
4.6	Nozzles.....	41
<b>5</b>	<b>Transport.....</b>	<b>42</b>
5.1	Safety notes.....	42
5.2	Delivery state.....	42
5.3	Temperature and humidity.....	43
5.4	Required tools for unloading and transport.....	44
5.5	Place of storage.....	44
5.6	Transport inspection and reporting of defects.....	44
5.7	Unpacking the machine.....	44
5.8	Relocation of the machine.....	45
<b>6</b>	<b>Setup and installation.....</b>	<b>47</b>
6.1	For your safety.....	47
6.2	Temperature and humidity.....	47
6.3	Space requirements.....	48
6.4	Setup.....	48
6.5	Connections.....	49
6.5.1	Mains connection.....	49
<b>7</b>	<b>Connection of additional components.....</b>	<b>50</b>
7.1	Exhaust system.....	50
7.2	Chiller.....	51
<b>8</b>	<b>Operation.....</b>	<b>52</b>
8.1	Before commissioning.....	52
8.2	Power On/Off.....	52
8.3	Control panel.....	54
8.4	Soft buttons on the touch display.....	55
8.5	Keypad.....	56

8.6	USB ports.....	59
8.7	Lenze placement.....	59
8.8	Focusing methods.....	60
8.8.1	Sonar Technologie™.....	62
8.9	Options.....	63
8.9.1	Rotary engraving attachment.....	63
8.9.2	Rotary engraving process.....	63
8.9.3	Installation and commissioning.....	64
8.9.4	Mounting the work piece in the rotary attachment.....	64
8.9.5	Gas-kit light.....	65
8.9.6	Temperature sensor.....	66
8.9.7	Vision Design&Position.....	67
8.9.8	Screw feet.....	69
9	Maintenance.....	70
9.1	Safety notes.....	70
9.2	Service life of safety-relevant components.....	70
9.3	Maintenance plan.....	71
9.4	Daily inspection of the safety circuits.....	71
9.5	Change the filter mat.....	72
9.6	Cleaning.....	73
9.6.1	Machine.....	73
9.6.2	Optics in general.....	73
9.6.3	Lens.....	74
9.6.4	Cleaning the mirrors.....	75
9.6.5	Ultrasonic sensor (Sonar Technology™).....	76
10	Troubleshooting.....	77
10.1	Error, cause and remedy.....	77
11	Contact details.....	79
12	Disassembly.....	80
13	Disposal.....	81
14	Appendix.....	82
14.1	Antwortformular Ruby Sprachen hinterlegt.....	85
15	Acronyms.....	86
16	Datasheet 8085 Speedy 360 C.....	88
17	CE_8085_8086_Speedy 360_Speedy 400_Konformitätserklärung_D.....	91

# 1 General Information

Aus Gründen der besseren Lesbarkeit wird in der Betriebsanleitung auf geschlechtsneutrale Endungen (z.B. "/innen") verzichtet. Es wird hiermit ausdrücklich erklärt, dass an allen Textstellen, wo natürliche Personen bzw. Personengruppen erwähnt werden, immer Menschen aller Geschlechter gemeint sind.

## 1.1 Information about this manual

**Before beginning any work on the machine, read this manual completely and carefully.  
Keep the manual for further consultation close to the machine.**

This manual describes how to operate the machine properly and safely. Be sure to follow the safety instructions given here, as well as any local accident prevention regulations and general safety regulations applicable to the field of usage. Before beginning any work on the machine, ensure that the manual, in particular the chapter entitled "Safety Information" and the respective safety guidelines, has been read in its entirety and fully understood.



### Information

Supplementary documentation can be found on the supplied storage medium. You can also request this from the manufacturer.

## 1.2 Explanation of symbols

Important technical safety notes and instructions in this manual are indicated by symbols. It is important to observe and follow these notes and instructions on workplace safety. Avoid accidents, personal injury and material damage to property by acting with extreme caution.



### Danger

This symbol indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



### Warning

This symbol indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



### Warning Dangerous electrical voltage

This symbol warns of potentially dangerous situations related to the electric voltage. Failure to observe the safety instructions leads to risk of serious injury or death. Particular care should be taken during maintenance and repair work.



### **Warning Laser**

This symbol warns of potentially dangerous situations related to the laser beam. Failure to observe the safety instructions leads to risk of serious injury.



### **Caution**

This symbol indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury.



### **Notice**

This symbol indicates potential risks of damage to the supported product (or to property).

In addition, non-observance may result in damage, malfunction or failure of the machine.



### **Information**

This symbol indicates tips and information which must be observed for efficient and trouble-free handling of the product.



### **Disposal**

This symbol indicates notes regarding the professional disposal of the product or accessories.

## 1.3 Liability and warranty

Warranty periods specified in the manufacturers “warranty terms and conditions” shall be binding for the buyer. If no warranty periods are specified, the general terms and conditions of sale, delivery and payment apply.

All information, illustrations, tables, specifications and diagrams contained in this operating manual have been carefully compiled according to the current state of technology. No liability is accepted with regard to errors, missing information and any resulting damage or consequential loss.

Strict compliance with the safety procedures described in this operating manual and extreme caution when using the equipment are essential for avoiding and reducing the possibility of personal injury or damage to the equipment. The manufacturer shall not be liable for any damage and or faults resulting from nonobservance of instructions in this manual.

Nonobservance of the operation, maintenance and service instructions described within this manual absolves Trotec Laser GmbH from any liability in case of a defect.

Furthermore, Trotec Laser GmbH shall accept no liability whatsoever for damage caused by the use of non-original parts and accessories.

Additionally, Trotec Laser GmbH shall not be held responsible for any personal injury or property damage, of an indirect or specific nature, consequential loss, loss of commercial profits, interruption to business, or loss of commercial information resulting from use of the equipment described in this manual.

It is strictly prohibited to make any alterations, to prepare translations, decompile, disassemble, reverse engineer or copy the software.

Trotec Laser GmbH reserves the right to update any of the information, illustrations, tables, specifications and diagrams contained in this operating manual with regard to technical developments at any time without notice.

## General Information

---

### 1.4 Scope of delivery (standard configuration)

- Laser machine
- Storage medium (includes instructions)
- Focus tool (as per lens order)
- Cleaning set for lenses
- Air nozzles (2 pieces:  $\varnothing 3$  and  $\varnothing 7$  mm)
- Lenses as per order
- Processing table as per order
- Allen key set (8 pieces)
- Exhaust connection cable (as per order)
- I/O plug
- Network cable

The actual scope of delivery may differ from the information provided here due to additional options or the latest technical modifications.

#### 1.4.1 Accessory box




- Lens Tissue (100pcs)
- Standard lens CO2 2.0" / flexx 2.85" additionally
- CAT 5e LAN cable 5,0m
- Storage medium
- Allen key kit
- Speedy Series Quick reference guide

## 1.5 Type plate

The data plate with the CE mark is located on the back of the unit.

Transfer the serial number, model and year of manufacture to your manual and always refer to this information in case of inquiries, problems with the unit, or spare parts orders.

Serial number:	
Model:	
Year of manufacture:	



## 2 Safety

### **TO AVOID POSSIBLE HARM READ AND FOLLOW THESE INSTRUCTIONS.**

The machine is built at the time of its development and production according to applicable, established technical rules and is considered to be safe to operate.

Dangers can be caused by the machine if the machine:

- is operated by unqualified personnel,
- the personnel have not been trained,
- the machine is used improperly or not as intended,
- or if the machine is used for other intended purposes.

This chapter provides an overview of all important safety aspects that are necessary for optimum protection of persons and safe and trouble-free operation of the machine. Other chapters of this manual contain specific safety notes for the avoidance and prevention of hazards.

### 2.1 General safety notes

#### 2.1.1 Intended use

**The machine described in this manual is used for cutting, engraving and marking materials using the software supplied.**

For information about materials, see chapter "[Materials list](#)". Alternatively, contact your Trotec representative or our technical support team in your area.

The unit may only be operated, maintained, and repaired by persons familiar with the intended application and the hazards inherent to the machine.

The machine and safety devices may only be operated in perfect condition and must comply with the requirements of the EU Machinery Directive.

The machine may only be operated in conjunction with a suitable and effective exhaust system.

The machine may only be used while it is being supervised.

Intended use also means that anyone who is responsible for the installation, commissioning, operation, maintenance and/or repair of the machine must have read and understood these instructions, and in particular, the "Safety" chapter. The instructions in this manual must always be followed.

The rotary engraving attachment may only be operated with cylindrical objects.

## 2.1.2 Improper use

Use of the machine for any purposes other than those intended or described in the present manual is regarded as improper and therefore prohibited. Trotec Laser GmbH will not accept any liability for damage caused by improper use. The operator is solely liable for all damages caused by improper use.

Non-observance of the operation, maintenance and service instructions described within this manual absolves Trotec from any liability in case of a defect.

## 2.1.3 Residual risk

Even if all safety regulations are observed, a residual risk remains when operating the machine.

The measures required to reduce any residual risks can be found in the following sections of chapter "[Secondary \(indirect\) hazards](#)".

## 2.1.4 Machine modification

It is strictly prohibited to alter, refit or modify the machine in any way without the express consent of the manufacturer.

Likewise, it is strictly prohibited to remove, bridge or bypass any safety devices. Operating conditions and connection and setup values stated in the data sheet must be complied with at all times.

Operation of the system is permitted only with original parts and accessories by the manufacturer. Use of third-party parts affects machine safety.

## 2.1.5 Operating modes

### NORMAL OPERATION

**For normal operation, the following conditions must be met:**

- Intended use of the machine (see chapter "[Intended use](#)").
- Operation by trained operating personnel.
- Fully functioning and installed safety and protective devices.
- Machine in perfect condition.
- Processing of permissible materials according to the material lists.
- Maintenance and service are not included.



#### Notice

During normal operation it is not necessary to wear safety glasses.

### SERVICE OPERATION

Service activities may only be carried out by authorized, trained service technicians. If side panels and covers are removed and protective devices are bypassed, this can result in direct and indirect scattered radiation. Service operation is declared to be laser class 4 and appropriate precautionary measures must be taken (see chapter "[Laser classes of this machine](#)").

#### 2.1.6 Applicable safety regulations

The following guidelines and regulations must be observed to avoid risks when operating Trotec laser systems.

### GUIDELINES/REGULATIONS

2006/42/EC	EC Machinery Directive
2014/30/EU	EMC Guideline

### APPLIED HARMONIZED STANDARDS

EN ISO 11553-1:2020	Safety of Machinery – Laser Processing Machines - Part 1: General safety requirements
EN ISO 12100:2010	Safety of Machinery – General Design Principles
EN ISO 13849-1:2018	Safety of Machinery – Safety-related Aspects of Control Systems, Part 1: General design principles
EN 60204-1:2018	Safety of Machinery – Electrical Equipment of Machines - Part 1: General requirements
EN 60825-1:2022	Safety of Laser Products – Part 1: Classification of equipment and requirements
EN 61000-3-2:2019	Electromagnetic compatibility (EMC) – Part 3-2: Limit values for harmonic currents
EN 61000-3-3: 2013 + A1:2019	Electromagnetic compatibility (EMC) – Part 3-3: Limit values for voltage changes / flicker
EN 61000-6-2:2019	Electromagnetic compatibility (EMC) – Part 6-2: Interference immunity for industrial areas
EN 61000-6-4:2019	Electromagnetic compatibility (EMC) – Part 6-4: Interference emission for industrial areas

### OTHER APPLIED TECHNICAL STANDARDS

EN 60825-4:2012	Safety of Laser Products – Part 4: Laser safety barriers
-----------------	--



### Notice

#### Observe applicable safety regulations.

Instructions and directives in this manual may differ locally, regionally, and internationally. Please observe the country-specific guidelines that apply to you.

The operator is responsible for meeting all safety requirements, as Trotec Laser GmbH has no influence on the correct use of the unit.

Adhere to official regulations for your operating site in accordance with the applicable local legal provisions (for accident prevention regulations or employee protection), e.g. DGUV regulation 11 for Germany.

## LASER CLASSES OF THIS MACHINE

A laser protection class characterizes the potential risk of accessible laser radiation.

The laser system complies with class 2 according to EN 60825-1 “Safety of Laser Products”.

The built-in laser source is class 4 according to EN 60825-1 and is labeled as such. During operation, laser class 4 is not accessible due to the safety features of the machine.

## DEFINITION OF LASER CLASSES

### Class 2 (US: class II)

The accessible laser radiation of Class 2 (US: Class II) laser systems does not pose any hazard for the skin. Diffuse reflections as well as any short-term irradiation of the eyes (exposure time max. 0.25 seconds) also pose no risk due to the low output power. However, it is possible to suppress the natural eyelid closure reflex and stare into the class-2 laser beam for a time long enough for the eyes to get injured.

### Class 4 (US: class IV)

Class 4 (US: class IV) high powered lasers (visible or invisible) considered to present potential acute hazard to the eye and skin for both direct and scatter (diffused) conditions.

Also have potential hazard considerations for fire (ignition) and byproduct emissions from target or process materials. It is the responsibility of the operator of the machine to take appropriate measurements to eliminate any dangers such as fire or explosions through the laser beam.

### LASER RADIATION WARNING



#### Warning Laser

##### Laser radiation of Class 2 (US: class II)

For Class 2 (US: class II) laser is short term exposure (up to 0.25 seconds) harmless to the eyes and can therefore be operated without additional protective measures. However it can cause irritation of the eyes if the natural avoidance reaction (staring into the laser beam deliberately) or eyelid closure reflex is suppressed.

- Do not suppress the eyelid closure reflex.
- Do not stare directly into the laser beam.
- Close eyes, turn away.
- Never look at the laser beam directly with an optical instrument, e.g. a lens.



#### Warning Laser

##### Laser radiation of Class 4 (US: class IV)

Exposure to laser radiation of Class 4 (US: class IV) can cause injury to the eyes and skin.

- The skin and eyes must not be exposed to direct or reflected or scattered radiation.
- Wear suitable laser safety protection glasses.
- When dealing with Class 4 (US: Class IV) laser machines, it is necessary to appoint a trained laser safety officer to evaluate potential hazards and to ensure that appropriate control measures are implemented.



#### Notice

##### Laser classification

It is the responsibility of the operator to comply with the national official and statutory regulations for the operation of a laser system with a build in laser source of class 4 (US: class IV).

## 2.2 Areas of responsibility

### 2.2.1 Responsibilities of the operator

#### The operator has the following responsibilities:

- It is the responsibility of the operator to comply with the national official and statutory regulations for the operation of a class 4 (US: class IV) laser system or laser system with a build in laser source of class 4 (US: class IV).
- In addition to the safety notes and instructions stated in this manual, consider and observe the local accident prevention regulations and general safety regulations that apply at the operation site of the machine.
- A CO<sub>2</sub> fire extinguisher must always be at hand, as the laser beam can ignite flammable materials.
- If the machine is used industrially, the operator is subject to the legal obligations concerning industrial safety.
- All personnel involved in installation, set-up, operation, maintenance and repair of the machine must have read and understood this manual and in particular the "Safety" section. The personnel must be trained and informed about all the functions, potential dangers and safety issues of the machine on a yearly basis.

- The user is recommended to prepare company internal instructions considering the occupational qualifications of the personnel employed in each case, and the receipt of the instruction/this manual or the participation in the introduction/training should in each case be acknowledged in writing.
- Keep the manual in the immediate vicinity of the machine so that it is accessible at all times to all persons working on or with the machine.
- Authority for the individual activities relating to the application of the machine (e.g. installation, operation, maintenance and cleaning) must be clearly defined and observed, so that no unclear competencies result under the aspect of safety. This applies in particular to work to be performed on the electrical equipment that may only be performed by qualified specialists.
- Maintenance and repair work as specified in the manual must be carried out regularly.
- For all activities concerning installation, set-up, start-up, operation, modifications of conditions and methods of operation, maintenance, inspection and repair, the switch-off procedures that may be provided in the manual must be observed.
- Provide appropriate personal protection equipment (e.g. protective goggles according to wavelength and laser power).
- The operator is responsible for the safety-related state of the machine.
- Do not store any flammable materials in the working area or in the immediate vicinity of the device. Particularly, residues of processed materials have to be removed to prevent any fire hazard.
- The operator must ensure cleanliness and accessibility at and around the machine by corresponding instructions and controls.

### 2.2.2 Responsibilities of the operating personnel

#### The operating personnel has the following responsibilities:

- Always wear personal protective equipment.
- The operator is required to check the machine including its safety devices for any externally detectable damage and deficiencies before starting work, and to immediately report any changes (including irregularities of the operating behavior) that may affect safety. It is important to ensure that the machine is only operated in perfect condition. For details, see chapter "[Maintenance](#)".
- The machine must not be left unattended while it is operating (supervised operation).
- Switch off the machine described herein at the main switch for periods of non-use.
- Operate the machine described here only with a lens in place. A missing lens may cause the unfocused laser beam to be reflected out of the housing.
- Stop this machine immediately in case of failure.
- No working methods are permitted that affect the safety of persons or of the machine.
- The machine and its components, such as the lens and mirrors, are to be kept clean at all times.



#### Caution

The adjustment of the beam path may only be carried out by service personnel of Trotec Laser GmbH.


### 2.3 Requirements for operating an service personnel

**The requirements for operating personnel are as follows:**

- Personnel must have read and understood the instructions, in particular chapter "[Safety](#)".
- Personnel must not be under the influence of drugs, alcohol, or medication that affects their ability to react appropriately.
- Personnel must be familiar with the use of the fire extinguisher provided .
- Personnel must be qualified to operate the machine through adequate and detailed training. If a member of staff does not have the required knowledge, they must be trained internally. A Trotec training course can be requested and recorded in the training/acceptance protocol (see "[Appendix](#)").

## 2.4 Warning and information labels

The warning and information labels are attached to the device at those points which could represent a source of danger before commissioning or during operation. Therefore, pay special attention to the information on the labels.




### Caution

#### Lost or damaged warning and safety stickers.

If any warning and safety stickers are lost or damaged, the user is not able identify risks anymore, and there is danger of injury.

- Replace lost or damaged labels immediately.
- Contact your Trotec Laser GmbH dealer for details.



### 2.5 Safety devices



#### **Warning**

##### **Danger from laser beam.**

Personal injury and damage to property may occur if the safety devices and protection devices are not fully functional.

- Do not remove, modify or deactivate the interlock safety switches or protective covers on the machine. Safety and protection devices must be fully functional at all times.
- In case of assumed or presumed damage of safety devices, disconnect the machine from the mains.
- Damaged safety and protection devices need to be replaced by a Trotec technician immediately.

### 2.6 Technical protective measures

#### 2.6.1 Main switch

Pressing the main switch on the backside of the machine to disconnect the machine from the mains power supply.

#### 2.6.2 Key switch

Turning the key switch to the “0” position de-energizes the motor, laser source, and electronics. It causes the machine to instantly stop and the laser source to switch off. Operation of the machine by unauthorized persons can be prevented by removing the key switch.

#### 2.6.3 Emergency stop button

Pressing the emergency stop button instantly stops the machine and switches off the laser source.

The laser beam is interrupted and all movements are stopped.

### **RESET THE EMERGENCY STOP BUTTON**



#### **Notice**

Eliminate the hazard before resetting the emergency stop button.



1. Turn the emergency stop button counterclockwise to unlock it so that the green marking is visible.
2. Restart the laser system using the key switch.

#### 2.6.4 Interlock safety switches

Interlock safety switch query the closed status of the acrylic top lid, side panels and front door. If the safety devices are open or not present, the laser cannot be operated. However, the pilot laser stays active.

#### 2.6.5 Acrylic top lid

The type of acrylic top lid depends on the laser type. It protects the operator from uncontrolled emission of dangerous laser radiation.

#### 2.6.6 Side cover

The side panels protect from laser light and must always be closed and properly attached.

#### 2.6.7 Temperature sensor

The temperature sensors ensure reliable temperature monitoring of the interior of the machine and are available as additional option.

#### 2.6.8 In case of safety device malfunction

Actual or presumed damage to the safety devices can cause injury or damage. Following measures must be carried out.

1. Press the emergency stop button.
2. Disconnect the machine from the mains.
3. Contact our Technical Support in your local area.

### 2.7 Secondary (indirect) hazards

See also "[Residual risk](#)".

#### 2.7.1 Fire hazard



##### **Warning** **Fire hazard**

Fire hazard from gas and processing of inflammable materials.

- Do not operate the device without supervision.
- Keep CO<sub>2</sub> fire extinguisher ready at hand in the immediate vicinity of the device.

If a main laser beam hits easily flammable material, e.g. paper, this may ignite and a fire can quickly occur. Therefore, before switching on the laser, you should make absolutely sure that there is no easily flammable material in the beam path.

Furthermore, gases that can form below the material to be processed may ignite. Especially if the extraction requirements are not met.

Inadequate care and cleaning of the system increases the risk of flame formation.

Regularly check the cooling slots of the cooling system.

#### 2.7.2 Gases, fumes and dust

Depending on the materials being processed and the parameters selected, laser processing may generate gases, fumes, aerosols or dust. Depending on the material, such by-products may be toxic. In individual cases, the reaction products may be electrically conductive dusts. If these enter electric systems, short-circuiting with personal injury and property damage may occur.

The operator is responsible for ensuring presence of a suitable extraction system and compliance with the relevant guidelines in order to protect persons and the environment. Find out about local guidelines.

The operator must also ensure that gases, fumes or dust do not settle on the processing lens. Any dirt accumulating on the processing lens can lead to loss of performance, poor processing results and damage to the device.

### 2.7.3 Hazards due to damaged optics



#### Warning

##### Damage to the lenses.

Dirty lenses absorb laser radiation, which can destroy them. Broken or damaged lenses and thermal decomposition of lenses release particles that are hazardous to health.

- Clean the deflection mirror and lenses in the laser beam guidance area regularly.
- Take particular care when handling, attaching and cleaning.
- Always apply even pressure to the lens and do not apply pressure to one side only.
- Do not use tools or hard objects to clean the surface.
- Do not touch the lens surface with your fingers.
- Only use cleaning cloths once, never repeatedly.
- In the event of broken or damaged lenses or thermal decomposition of lenses, follow the appropriate protective measures (see the following chapter).
- Disposal must be in accordance with local laws.
- **Scratched lenses or lenses with a burn mark must not be used!**

#### SCRATCHED OR DAMAGED LENS SURFACE

Please note that scratches in the surface coating may produce small amounts of toxic emissions that are hazardous to health if inhaled or swallowed.

#### THERMAL DECOMPOSITION

Thermal decomposition produces smoke from selenium and zinc oxides. There is a risk of poisoning if inhaled or swallowed. Indicators of thermal decomposition of ZnSe (zinc selenide) are deposits in the form of white or red powder and an unpleasant odor.

#### BROKEN LENSES

When optical components made of ZnSe (zinc selenide) are destroyed, toxic dust and vapors are produced, which must not be inhaled. The dust can also cause irritation to the eyes, skin and respiratory system. If a lens is destroyed during operation, extra care must be taken when removing and cleaning it.

### 2.7.4 Protective measures for damaged optics

#### Protective measures in case of thermal decomposition and scratched or broken lenses

- For disposal use a protective mask or respiratory filter to prevent inhalation or ingestion of thorium.
- Wash hands thoroughly after contact with a scratched coating.

#### Protective measures in case of a broken lens

- Upon perception of an unpleasant odor, switch off the machine.
- Hold your breath.
- Leave the area of the machine.

- Before approaching the system again, wait for at least 30 min until the reaction has abated.
- Wear proper protective clothing (respiratory protection, protective goggles, protective suit, rubber or plastic gloves).
- Provide ventilation.
- When approaching the system again, pay attention to odors.
- Remove all lens fragments.
- Avoid raising or dispersing dust.



### Disposal

The ZnSe dust and the lens are to be collected drily and disposed of with fragments, broom, shovel and protective clothing into hermetically sealable containers or plastics bags as hazardous waste.

**Do not dispose of optical components as domestic waste, and do not let them enter the sewer or water bodies.**

**Dispose of according to regulations and laws valid in the users' country.**



### Warning


**Danger from laser beam.**

Invisible laser radiation of reflecting materials can cause serious injury or material damage.

- Only material according to the intended use of the machine may be used.
- Do not use material with high reflecting surfaces such as aluminum, chromium, precious metals, metal foils, stainless steel, brass, copper and titanium.
- Take special care with surfaces formed convex and concave.
- Do not leave or put objects on the work surface/working area.

## REFLECTION OF LASER RADIATION

The law of reflection applies to the reflection of laser radiation: **Angle of incidence = angle of reflection**



No.	Description
1	Directed reflection: Reflected laser beam on a smooth surface.
2	Directed reflection: Reflected laser beam on an inclined surface.
3	Diffuse reflection: Reflected laser beam on a rough surface.
4	Directed reflection: Horizontally reflected laser beam on a smooth surface.

## 2.8 In case of emergency

### WHAT TO DO IN THE EVENT OF A MALFUNCTION

- In unusual operating conditions, open the lid to stop the machining process, press the emergency stop button, and switch off the machine.
- If necessary, disconnect the machine from the main power supply.
- Inform the laser safety officer and your supervisor.
- Repair work must only be carried out by Trotec Laser GmbH service technicians.
- In the event of fire: Fight the fire with a CO<sub>2</sub> fire extinguisher if it is safe to do so.



#### Notice

After a deletion, Trotec Technical Support must be involved before the system is put back into operation.


### **WHAT TO DO IN THE EVENT OF AN ACCIDENT; FIRST AID**

- If eye damage occurs due to laser radiation, the casualty must be immediately seen by an ophthalmologist.
- The first aider must always ensure that they protect themselves.
- De-energize the unit and secure it against restarting:
  - Remove the key switch.
  - Unplug the mains cable.
- Remove the injured person from the danger zone and provide first aid.
- Call an ambulance!

### 3 Technical Data

→ The technical data sheet can be found in the appendix of this manual.

#### 3.1 Dimensions and weight



	Description	Dimension
A	Height front side with open lid	1774 mm (69.8 inch)
B	Height front side	998 mm (39.3 inch)
C	Depth with exhaust hose connection and gas kit light	843 mm (33.2 inch)
	Depth without exhaust hose connection and gas kit light	790 mm (30.7 inch)
D	Length	1221 mm (48 inch)
E	Depth with exhaust hose connection but without gas kit light	819 mm (32.2 inch)
F	Height back side with Vision Design&Position	1066 mm (42 inch)
	Weigh (depending on the laser power)	235 bis 250 kg (518 to 551 lbs)

### 3.2 Network connection

#### RECOMMENDATIONS PC

##### Client

- Operating system: Windows 64-bit
- Screen Resolution: min. 1920x1080 (FullHD)
- Browser: latest Google Chrome
- RAM: min. 4GB
- Processor: Min. i7 or comparable


##### Network

- DHCP Active
- 100Mbit Speed
- CAT5e or higher
- Wifi: 2,4GHz or 5GHz

### 3.3 Computer connection

Connect the machine to the local network port using a LAN cable or plug in the optional Wifi dongle on the back of the machine.

The network settings must be set up when the machine is first started.



#### Information

You can find information on the connections in chapter "[Overview of unit](#)".

### 3.4 Requirements for the electrical connections of the machine

Laser power	55–80 W (TL4 CO <sub>2</sub> ) 20-50 W (fiber)		85–100 W (TL6 CO <sub>2</sub> ) 20-50 W (fiber)	105–120 W (TL8 CO <sub>2</sub> ) 20-50 W (fiber)
Voltage	230 V~	115 - 230 V~	230 V~	230 V~
Fuse	16A (T)*		12A (T)*	12A (T)*
Power consumption <b>AC</b> (air-cooled) and <b>LC</b> (liquid-cooled)	1590 W	1590 W	2100 W	2100 W

\* T = time delay (slow release)



#### Caution

Inadequate or inappropriate power sources can lead to machine damage and are not covered by any liability.

Verify that the electrical outlet is capable of providing the proper voltage, frequency and amperage required by the laser machine described in this manual.



#### Caution

Unstable mains voltage, mains voltage disturbances and voltage peaks may interfere with and damage the electronics of the laser machine.



#### Notice

Use an individual circuit for the laser machine and the PC and an individual circuit for the exhaust system. Install your computer to the same circuit as the laser machine to prevent electromagnetic interactions.

Furthermore it is highly recommended that you use a overvoltage protection switch to protect your computer equipment.

If electrical power fluctuations, brownouts or power outages are a problem in your area, an electrical line stabilizer, UPS (Uninterruptible Power Supply) or backup generator are required. When installing any of these devices, ensure that they meet the electrical requirements of the laser machine.

### 3.5 Exhaust system requirements



#### Danger

##### Danger of emission of toxic gases, vapors or dust.

During laser operation, toxic aerosols may be produced.

- The laser system may be operated only with properly installed and operating exhaust system.
- Check with the material manufacturer for its toxic effect.



#### Caution

The laser may only be operated with properly installed and operating exhaust system. Damage to the system, caused by the use of not any exhaust system or improper extraction equipment, will not be covered by any liability.

The requirements for the exhaust system and recommended Trotec exhaust systems for standard applications depend on the processing table installed in the machine. We recommend consulting with a qualified Trotec technician.

#### RECOMMENDED EXHAUST SYSTEMS:

Exhaust system	Speedy 360
Atmos Pure 300	✓
Atmos Pure 600	✓
Atmos Duo Plus	✓
Vent Set 400	✓ (without vacuum table)
Vent Set 500	✓



#### Notice

Connection has to be carried out by our Technical Support.

Observe instructions for operation and maintenance according to the operating manual of the exhaust system.

#### TECHNICAL DATA FOR THE EXHAUST SYSTEMS:

Exhaust system	Hose connector $\varnothing$ [mm] (internal diameter)	Volume flow rate [m <sup>3</sup> /h]	Pressure [Pa]
Atmos Pure 300	(3x) 80	352 (115V) 378 (230V)	6500 (115V) 8000 (230V)
Atmos Pure 600	(3x) 80	(2x) 378	8000
Atmos Duo Plus	70 / 70 / 45	(2x) 320	8500 (230V)
Vent Set 400	100	max. 1000	max. 3800

Exhaust system	Hose connector $\varnothing$ [mm] (internal diameter)	Volume flow rate [m <sup>3</sup> /h]	Pressure [Pa]
Vent Set 500	100	max. 1200	max. 7000

**REQUIREMENTS FOR THE EXHAUST SYSTEM:**

Machine	Volume flow rate [m <sup>3</sup> /h]	Pressure [Pa]
Speedy 360	350	3500

The exhaust connection on the side of the machine is used as the measuring point for volume flow and pressure. Pressure losses through hoses or pipes or filters in the exhaust system must be determined and taken into account when selecting the exhaust system.

A powerful exhaust system prevents a reduction in the service life of the lenses and mechanical components, the cutting quality and the laser power acting on the workpiece caused by vapors and dust remaining in the machine.



**Notice**

The exhaust power available for the application will be reduced by e. g. bends, small hose diameters and long hoses.

**You should therefore note the following:**

- Avoid bends.
- Keep hose as short as possible.
- Use hose diameters as large as possible.

Applications generating large amounts of dust or fumes may require a stronger exhaust system. Use of separate exhaust systems for head and table exhaust may also be necessary.

In this case it is absolute necessary to consult your distributor.

3.6 Materials list

Material	Cutting		Engraving		Marking	
	CO <sub>2</sub>	Fiber	CO <sub>2</sub>	Fiber	CO <sub>2</sub>	Fiber
<b>Metals</b>						
Aluminum				✓		✓
Anodized aluminum				✓	✓	✓
Chromium plated surfaces				✓		✓
Precious metals				✓		✓
Metal foils up to 0.5 mm (aluminum, brass, copper, precious metal)		✓		✓		✓
Stainless steel				✓		✓

## Technical Data

Material	Cutting		Engraving		Marking	
	CO <sub>2</sub>	Fiber	CO <sub>2</sub>	Fiber	CO <sub>2</sub>	Fiber
coated metal (lacquered)			✓			
Brass				✓		✓
Copper				✓		✓
Titanium				✓		✓

Material	Cutting		Engraving		Marking	
	CO <sub>2</sub>	Fiber	CO <sub>2</sub>	Fiber	CO <sub>2</sub>	Fiber
<b>Plastics</b>						
Acrylonitrile butadiene styrene copolymer (ABS)	✓		✓			✓
Acrylic (PMMA), e.g. Plexiglas®	✓		✓			✓
Rubber (stamp rubber)	✓		✓			✓
Polyamide (PA)	✓		✓			✓
Polybutylene terephthalate (PBT)	✓		✓			✓
Polycarbonate (PC)	✓		✓			✓
Polyethylene (PE)	✓		✓			✓
Polyester (PES)	✓		✓			✓
Polyethylene terephthalate (PET)	✓		✓			✓
Polyimide (PI)	✓		✓			✓
Polyoxymethylene (POM) e.g. Delrin®	✓		✓			✓
Polypropylene (PP)	✓		✓			✓
Polyphenylene sulfide (PPS)	✓		✓			✓
Polystyrene (PS)	✓		✓			✓
Polyurethane (PUR)	✓		✓			✓
Foam material (PVC free)	✓		✓			✓

Material	Cutting		Engraving		Marking	
	CO <sub>2</sub>	Fiber	CO <sub>2</sub>	Fiber	CO <sub>2</sub>	Fiber
<b>Other materials</b>						
Wood	✓		✓			
Mirrors				✓		✓
Stone			✓			
Paper (white)	✓		✓		✓	
Paper (colored)	✓		✓		✓	✓
Foodstuffs	✓	✓	✓		✓	

Material	Cutting		Engraving		Marking	
	CO <sub>2</sub>	Fiber	CO <sub>2</sub>	Fiber	CO <sub>2</sub>	Fiber
Leather	✓		✓		✓	
Fabrics	✓		✓			
Glass			✓			
Ceramics				✓	✓	✓
Cardboard	✓		✓		✓	
Cork	✓		✓		✓	
Marking agent (on metal or ceramic/glass) e.g. markSolid			✓		✓	



### Warning

#### Non-approved materials:

- Leather and vinyl with chrome (VI)
- Carbon fibers (carbon)
- Polyvinyl chlorides (PVC)
- Polyvinyl butyral (PVB)
- Polytetrafluoroethylenes (PTFE /Teflon)
- Beryllium oxide
- Materials containing halogens (e.g. fluorine, chlorine, bromine, iodine and astatine), epoxy and phenolic resins.



### Notice

Ask a Trotec Laser representative about the suitability of any materials that are not on the list to avoid any potential risks arising from a chemical reaction, and to preserve the warranty. For detailed information, please contact Trotec Laser Technical Support. Unless written approval is given, Trotec Laser accepts no liability and the warranty will be void.

#### Care should be taken with the following materials:

- Manganese
- Chrome
- Nickel
- Cobalt
- Copper
- Lead
- and when processing materials with the label “flame-retardant”, as they often contain bromine.



### **Warning**

#### **Serious injury or material damage.**

The use of prohibited or unreleased materials can cause serious injury or material damage and will not be covered under warranty.

Only use approved and released materials.



### **Notice**

Please contact our experienced application specialists or a sales partner near you, if:


- You are unsure about the processing of a material.
- You have additions for further materials for us or in your opinion a material was not listed.

We recommend performing a material processing test with the above mentioned material, using the appropriate configuration.

Trotec Laser GmbH assumes no responsibility for any consequences of laser processing in any application, especially with medical or pharmaceutical applications.

## 4 Machine overview

### 4.1 Anlagenübersicht




No	Description	No	Description
1	Top lid	8	Keypad
2	Vision Design&Position	9	Front door
3	X-axis	10	Laser head
4	Emergency stop button	11	Working table
5	Key switch	12	Ruby server status LED
6	USB ports	13	LED Interior lighting
7	Touch display		

## Machine overview




No	Description	No	Description
14	Connector for exhaust tube (working area)	16	Type plate
15	Cover for laser source	17	Connector for exhaust tube (working table)



No	Description	No	Description
18	I/O interface	22	USB port for WiFi dongle
19	Service plug connector	23	Fuse
20	Connector for exhaust tube	24	Mains connection
21	LAN	25	Main switch

## 4.2 Ruby server status LED

The Ruby server status LEDs are located on the left side above the LED interior lighting inside the laser machine.



Description

- 1** Green: power
- 2** Yellow: activ
- 3** Reset button

### 4.3 Front door



Loading and unloading of heavy and bulky parts or replacement of the table is very comfortable thanks to the front door that can be opened downwards.



#### Notice


EN

EN




### 4.4 Tables (multifunctional table concept)

#### MULTIFUNCTIONAL BASE FRAME



The multifunctional base frame is bolted to the mounting frame, which is attached to the Z-axis.

### ALUMINUM CUTTING GRID TABLE




The robust universal cutting table offers great stability and is especially suitable for cutting tasks with parts smaller than 100 mm, as they remain flat in position after cutting.

### FERROMAGNETIC ENGRAVING TABLE



The ferromagnetic construction allows thin materials, such as paper or film, to be easily attached with magnets. A flat processing area is an essential criterion for optimum results in laser engraving and laser marking.

### VACUUM TABLE



The vacuum table attaches the material to the working table by means of negative pressure. This ensures both correct focusing over the entire surface and even better engraving results. The vacuum table is the ideal choice for thin and light materials, e.g. paper and film, which tend not to lie completely flat on the base.

**HONEYCOMB CUTTING TABLE**





The honeycomb cutting table is especially suitable for applications that require minimal back reflection and optimal flatness, such as when cutting membrane keyboards.

Available in the following sizes: 12.7 mm nominal honeycomb size  
6.4 mm nominal honeycomb size

4.5 Lens(es)

CO <sub>2</sub>		Fiber		flexx	
	1.5" red Part No. 85973		3.2" green Part No. 1380		2.85" gold  (Standard) Part No.: 9567
	2.0" black (Standard) Part No.: 85974		5.0" light blue Part No. 37781		
	2.0" CL brown Part No. 95909				
	2.5" silver Part No. 85975				

CO <sub>2</sub>	Fiber	flexx	
 <p>4.0" blue Part No.: 90026</p>			
 <p>4.0" CL violet Part No. 143502</p>			

#### 4.6 Nozzles



Ø 3 mm

Short nozzle with small hole.



Ø 7 mm

Short nozzle with big hole.

### 5 Transport

#### 5.1 Safety notes



##### **Warning**

##### **Risk of injury**

There is risk of injury from falling parts during transport, loading and unloading of the machine.

- Follow the safety notes.

##### **Observe the safety notes to avoid damage to the machine from improper handling during transport:**

- Always move the machine with utmost care and attention.
- Transport the machine/machine components only in its original packaging.
- Take the machine's center of gravity into account when transporting it (minimize the risk of tipping over).
- Observe the packaging symbols (e.g. transport the machine only in upright position).
- Take measures to prevent the machine from slipping sideways, tipping or falling over.
- Transport the machine as carefully as possible in order to prevent damage.
- Avoid vibrations.
- When transporting the machine overseas, the device must be packaged airtight and protected against corrosion.
- When transporting outdoors, transport only in vehicles with roof or sufficient weather protection.
- Protect the machine against transportation damage using straps and inserts, and leave sufficient gaps to other transported items.
- Do not place any other loads or items on the machine or machine components.

#### 5.2 Delivery state

Unless otherwise agreed, the machine is delivered in a wooden crate that contains the laser machine and additional accessories. Transport the machine only in its original packaging.




##### **Caution**

##### **Risk of injury**


There is risk of injury from falling parts during transport, loading and unloading of the machine.

- Follow the safety notes.

**OBSERVE THE PACKAGING SYMBOLS:**



**NOTE THE SHOCKWATCH SIGN:**



5.3 Temperature and humidity

**Transport conditions**

Transport temperature (ambiente temperature):	-10 °C to +40 °C (14 °F to 104 °F)
Relative humidity:	Maximum 70%, non-condensing

- Avoid high temperature fluctuations.

**Storage conditions**

Storage temperature (ambiente temperature):	0 °C to +30 °C (32 °F to 86 °F)
Relative humidity:	Maximum 60%, non-condensing

- Avoid high temperature fluctuations.

### 5.4 Required tools for unloading and transport

#### **REQUIRED TOOLS:**

- Unloading - Forklift
- Transport - Pallet truck

### 5.5 Place of storage

- Keep the machine sealed in its packaging until it is assembled or installed.
- The storage location must be dry, free of dust, caustic materials, vapors and combustible materials.
- Store the machine in a storage room or ensure it is adequately packed and protected from the weather.
- Avoid exposure of the machine to shocks or vibrations.
- Avoid extreme temperature fluctuations.
- Take particular care when packing away electronic components.
- When storing for a longer period, apply a coat of oil to all bare-metal machine parts.
- Regularly check the overall condition of all parts and of the packaging.

### 5.6 Transport inspection and reporting of defects

- Immediately after receipt inspect the delivery to ensure that it is complete and has not suffered any damage.
- If any transport damage is visible, do not accept the delivery, or accept it only with reservation.
- Record the scope of the damage on the transport documents or delivery note.
- For all defects that are not discovered upon delivery, be sure to report them as soon as they are detected, since damage claims must be filed within a certain period, as mandated by law.

### 5.7 Unpacking the machine

Only trained and authorized personnel are permitted to transport and unpack the machine. To avoid falling off of any wooden parts or tipping of the machine, be very careful when opening the transport case.



#### **Notice**

Keep the original packaging case, in case of machine needs to be transported or relocate.

Dispose all waste according to the applicable waste disposal law.



### Caution

The lens unit should be unpacked only after installation of the machine. The lenses are high-quality optical components which must be kept clean in order to ensure optimum marking results. Never touch the lenses with bare fingers.

### STEPS:

1. Position the transport case vertically on level ground (using a pallet truck or forklift).
2. Remove any vertical tightening straps.
3. First remove the top and afterwards the side plates of the transport case.
4. Slide out the two wooden rails in the form of ramps that are stored beneath the machine.
5. To secure the machine against moving, the wheels are locked using wooden blocks.  
In order to remove those blocks, put the two wooden rails together, push the upper part of the rails under one side of the machine and press down the rail in order to reach a levering effect.
6. Pull out the blocks.
7. Repeat this procedure on the opposite side as well.
8. Now you can pull out the blocks.

## 5.8 Relocation of the machine

### STEPS:

1. Switch off the machine.
2. Disconnect the power cable.
3. Remove the exhaust system.
4. Reposition the machine (e.g. with auxiliary equipment if necessary) and place it on a level, clean floor.
5. Adjust the machine.
6. Initial commissioning of the electrical system.
7. Carry out function test.



### Caution

Transport the machine only in its original packaging. Ensure the wooden crates are properly secured otherwise the crates can slip, tip or fall over during transport.

Observe the corresponding safety norms and regulations from the chapters “Safety notes” and “Transport”.

- When transporting over long distances, use transport boxes including transport securing.



### **Notice**

If you would like to relocate the machine, contact our experienced Technical Support in your local area.

## 6 Setup and installation

### 6.1 For your safety

**Notice**

The setup has to be carried out by Technical Support.

### 6.2 Temperature and humidity

**Ambiente conditions**

Operating temperature (ambiente temperature):	+15 °C to +25 °C (59 °F to 77 °F)
Relative humidity:	45% to 65%, non-condensing


- If the system has been exposed to large temperature fluctuations, it must first be brought back to room temperature before commissioning.

**ENVIRONMENTAL CONDITIONS**

- Provide sufficient illumination at the workplace.
- Ensure a dust-free environment (II° according to IEC60947-1).
- Shielding from EMC.
- Freedom of interfering electrical installations, hoses and pipe lines.
- Power supply free of fluctuations.

### 6.3 Space requirements

Ensure there is shielding or sufficient clearance to or from the wall and neighboring objects.



### 6.4 Setup

#### **OBSERVE THE FOLLOWING STEPS:**

1. Transport the machine to the installation location according to the specifications stated in the chapter “Transport”.
2. Make sure all the packaging material has been removed.
3. Remove any transport protections.
4. Install the two exhaust connectors at the rear of the machine.  
They have been removed for safety reasons and for transport through doors.
5. The machine must stand upright.
6. Make sure the protective glass is intact.
7. Now connect the electrical components.
8. Set up the network connection to the machine.



#### **Caution**

Install the connections exactly in the order described, otherwise electrostatic charging can damage your computer and/or the electronics of the laser system.

## 6.5 Connections

### 6.5.1 Mains connection

Connect the end of the mains cable to a fused socket.



#### **Warning Dangerous electrical voltage**

**Wrong voltage can cause damage to the machine.**

Do not operate the machine, if the mains voltage does not match the voltage required by the exhaust system, as this may cause damage to the machine.



#### **Notice**

Depending on the laser power and region, the main fuses are either covered or open on the back of the machine.

### 7 Connection of additional components

#### 7.1 Exhaust system



#### **Warning Dangerous electrical voltage**

**Wrong voltage can cause damage to the machine.**


Do not operate the machine, if the mains voltage does not match the voltage required by the exhaust system, as this may cause damage to the machine.

Make sure that the mains voltage matches the voltage required by the exhaust system.

#### **Connecting:**

1. When using an original Trotec exhaust system, also connect this, using the exhaust connection cable included, to the exhaust cable connection on the laser.
2. Plug the ends of the exhaust hose into the exhaust nozzle that is intended for this purpose on the exhaust system and on the laser. The position of the connector depends on the type of the exhaust system.
3. Plug in the mains cable of your exhaust system into the mains socket.

Follow the operation and maintenance instructions in the Manual of the exhaust system.



- ① Intake connector for exhaust hose
- ② Connector for exhaust connection cable
- ③ Main cable to main socket
- ④ Safety switch

### 7.2 Chiller

#### **WATER COOLING UNIT (CHILLER)**

When using water-cooled laser sourced, a cooling unit is required. The mixture of distilled water and special additives protects and prevent the formation of algae and limescale deposits in the cooling unit and laser source. This ensure operation and longevity of the laser cooling unit and laser source

#### **MIXTURE**

Distilled water and the additive \*Watertreatment-Kit 480-WTK-10.88.



#### **Caution**

Do NOT use glycol-containing additives!

#### **FILLING AND WATER REPLACEMENT**

Fill the cooling unit with distilled water and add the additives (the kit is pre-dosed and a safety handling manual is included).



#### **Notice**

The conductivity of the water must not exceed 1000  $\mu$ S. This value will not be reached if mixing the distilled water and additive accurately. A conductivity meter is available on request from Trotec Laser GmbH.

Water replacement must be carried out once a year. Empty the cooling unit, clean it with distilled water, fill it with fresh distilled water and add new additives.



#### **Notice**

In case of extremely strong impurities the additive \*Nalco CCL2567 is recommended for the cleaning rinse.

#### **\* ORDER ADDRESS FOR ADDITIVES:**

CTA GmbH

Voithstraße 1

71640 Ludwigsburg / Germany

E-mail: [service@cta-gmbh.de](mailto:service@cta-gmbh.de) or [slund@nalco.com](mailto:slund@nalco.com)

Order number water treatment kit: Watertreatment-Kit 480-WTK-10.88.

Order number cleaning rinse: Nalco CCL2567

### 8 Operation



#### **Warning**

##### **Personal injury or damage to property due to improper operation.**

Improper operation can lead to serious personal injury or damage to property.

- Work on the laser machine may only be carried out by authorized and instructed personnel familiar with the operation of the machine, observing all safety regulations.

#### 8.1 Before commissioning

##### **BEFORE COMMISSIONING, CHECK THE FOLLOWING POINTS:**

- With regard to completeness, and the technically perfect condition of the machine and safety equipment, see chapter "[Daily inspection of the safety circuits](#)".
- Order and cleanliness in the workstation.
- Cleanliness of optical components (free of dust and dirt).
- Activated exhaust system.
- Complete electrical installation.
- Correct input voltage of the electrical installation.
- Environmental conditions based on technical specification.
- For compliance with all regulations and laser safety measures, see chapter "[Safety](#)".
- Ensure compliance with all laser safety precautions as per chapter "[Safety](#)".

If any faults or functional deviations occur while checking the points listed, the machine is not considered to be safe to operate and must not be used until the fault has been rectified!

If you have any questions, please contact our experienced technical support team in your area.

#### 8.2 Power On/Off



#### **Notice**

In order not to restrict or obstruct the freedom of movement of the mechanics, no objects of any kind may be located in the machining area.

All safety protection covers have to be fully functional and closed.

## SWITCH ON THE LASER:



1. Switch on the main power supply using the main switch on the back of the machine.

The built-in Ruby server starts

2. Turn the key switch clockwise to the vertical position to activate the touch display.

To start the machine, turn the key switch to the right and hold it against the force of the spring. As soon as the machine starts, release the key switch.

3. The initialization process starts.
4. A signal tone is heard when the initializing run of the axes is complete.
5. The unit is ready for use once Ruby has fully started.



### Notice

Additionally the ready-to-use state is indicated through the slow flashing of the green status LEDs.

### TO SWITCH OFF THE MACHINE:

1. Turn the key switch to the left.

The touch display switches off, the axes are de-energized; the server remains active.




2. Switch off the main power supply to the machine by pressing the main switch on the rear of the machine.



### 8.3 Control panel

The control panel is the whole unit of the machine control.




- 1 Emergency stop button
- 2 Key switch
- 3 USB ports
- 4 TouchDisplay
- 5 Soft buttons
- 6 Keypad
- 7 RFID sensor

## 8.4 Soft buttons on the touch display


**With the soft buttons on the touch display you can:**

- call up the jobs in the queue
- switch on the air assist
- switch the exhaust system on and off
- and set the laser machine to standby mode.



- 1 Queue
- 2 Air assist
- 3 Exhaust system
- 4 Standby

### 8.5 Keypad



- 1 Start/Pause/Repeat-button**
- 2 Stop-button**
- 3 Status indicator** LED On: The machine is processing data.
- 4 Laser head control button X/Y**
  - travel distance in X-direction
  - travel distance in Y-direction
- 5 RFID-Control display**
- 6 Working table control button Z**
  - Up-button
  - Down-button
  - Automatic focusing



**Start/Pause/Repeat-button**

**Start:**

- Press this button to start a job.

**Pause:**

- Press this button to pause the job which is currently being processed.
- Press this button again to continue the job.

**Repeat:**

- Press this button after a job was finished to repeat the actual job.

**Meaning of the LEDs:**

LED	Description
Green, flashing slowly (0.5 Hz)	All covers are closed. Machine is ready.
Green, flashing fast (2 Hz)	Minimum one cover is open.
Blue + Green, permanent	Data available. Pause-mode active.
Green, permanent	Job is running. Processing and receiving data.



**Status indicator**

LED On: The machine is processing or receiving data.



**Laser head control button X/Y**

- Press one of these buttons to manually move the laser head to the right, left, front or back (travel distance in X/Y-direction).
- Press two of the for Laser head control buttons X/Y simultaneously in diagonal direction to move the laser in diagonal direction (X+/Y+, X+/Y-, X-/Y-, X-/Y+).



### Working table control button Z

- Press one of these buttons to manually move the working table up or down (travel distance in Z-direction).
- By simultaneous pressing of the Up-button + Down-button, the activation of the automatic focusing starts and the working table is moving automatically upwards.

Press any button in X-, Y-, or Z-direction to stop the automatically movement.

#### Activation of the automatic focusing:

The laser beam gets automatically focused on the work piece (depends on the selected lens). When there is no work piece on the working area, the focus is on the table or rather on the tabletop.

Sonar Technology™:

Focusing on the material which is below the sensor.



#### Caution

If there is no material on the cutting table, it could lead to a collision of the laser head ("head crash").




### Stop-button

- Press this button to stop the current working process.


## 8.6 USB ports

There are two USB ports on the control panel.



Charge (max. 2A) = Charging port  
 Data (500mA) = USB port (USB stick, HDD,..)

## 8.7 Lense placement




1. Loosen lens by turning the clamping ring inwards.
2. Remove lens.
3. Check the lens for damage.

See chapter [""](#)



4. If necessary, clean both sides of the lens with cleaning liquid and cleaning tissue.



5. Insert the lens with the lettering facing up, either above or below the clamping ring depending on the lens type.
6. Fixate the lens with the clamping ring.

### THE FOLLOWING LENSES MUST BE INSERTED BELOW THE CLAMPING RING:



1.5"



2.0"



#### Notice

All other available lenses must be inserted above the clamping ring.

## 8.8 Focusing methods

Precise laser engraving depends on several factors. Apart from the right choice of lens, working tables and a corresponding exhaust system, correct focusing plays a key role.

The correct setting of the focus, which means the right distance between the laser head and the material to be engraved, is crucial for a perfect application result.



#### Notice

The machine described in these manuals is equipped either with light barrier focus or Sonar Technology™.

#### Manual focus mode

- Focus tool

### Automatic focus modes

- Sonar Technology™ (automatic focusing with ultrasonic sensor)
- Light bar focus



#### Caution

If workpieces with more than 66.14 lbs (30 kg) have been placed on the table, the table must not be moved up or down anymore as this might damage the mechanics of the machine.

It is mandatory to focus on the height of the material before loading material of 66.14 lbs (30 kg) and above.



#### Notice

Defects from head crashes (working head hits material or working table) are excluded from warranty.



#### Notice

The machine described in these manuals is equipped either with light barrier focus or Sonar Technology™.



#### Notice


The equipment of the machine may vary depending on the model.

### 8.8.1 Sonar Technologie™



#### Caution

If the ultrasonic sensor is heavily soiled, the laser head may be damaged if it therefore hits the material or the worktable.



1. Make sure that the ultrasonic sensor is cleaned.
2. Select the correct lens in the control software settings.
3. Move the laser pointer over the workpiece to the surface to be focused.
4. Simultaneously press the two keys of the working table control button Z (1) so that the working table automatically moves to the focus position and the laser beam is focused on the workpiece.
5. Focusing completed and laser processing can begin.



#### Notice

This focusing mode is especially well-suited for all sound-relecrive materials.

## 8.9 Options

### 8.9.1 Rotary engraving attachment

The rotary engraving attachment is used for engraving cylindrical workpieces.



#### Caution

##### Damage to electronics.


Inserting or removing the Rotary attachment while the machine is turned on may irreparably damage the electronics.

Switch off the machine before inserting or removing the Rotary attachment.

#### Device with cone:

Max. workpiece diameter: 207 mm

Max. workpiece length: 550 mm



Device with cone


#### Device with rollers:

Max. workpiece diameter: 96 mm

Max. workpiece length:

$\varnothing \geq 58 \text{ mm} = 679 \text{ mm}$ ,



$\varnothing \leq 58 \text{ mm} = 745 \text{ mm}$




Device with rollers

### 8.9.2 Rotary engraving process

1. Create a graphic using the graphics software.	
2. Select the Rotary engraving option from the menu bar and specify the diameter of the item.	

3. Select the job from the list and place it in the marking field.	
4. Start the engraving process.	

### 8.9.3 Installation and commissioning



1. The machine must be switched off.




#### **Warning Dangerous electrical voltage**

If the rotary attachment is connected during operation, the connections and the electronics will be damaged. Such damage is excluded from the warranty.

1. Place the rotary attachment on the base frame to the ruler using the insertion handles.
2. Connect the device with the connecting cable via the connector on the left side of the housing.


### 8.9.4 Mounting the work piece in the rotary attachment

1. Measure the diameter of the workpiece.
2. Adjust the height and angle of the system by loosening and fixing the levers.



Levers for fixation of height and angle

- Loosen the slider by using the lever in order to clamp the workpiece between the two cones or rolls.




Slider inclusive lever

- Switch on the laser. The axis automatically moves over the middle of the rotary attachment.
- Position the laser head over the workpiece at the position where you want to engrave.
- Focus the object with the focus tool. The engraving area must be parallel to the X axis. If necessary, do this with the aid of the angle adjustment. Do not touch the lens holder.

### 8.9.5 Gas-kit light

The compressed air connected to the Gas-Kit light must be dry and oil-free and may have a maximum of 10 bar at 150 lt/min.



1. To adjust the air pressure, lift the adjustment knob of the air pressure regulator and turn it until the air pressure display shows the desired value.
2. Lock the set pressure by pressing the adjustment knob downwards again.



### Notice

Turn the regulator to a maximum of 0.4 MPa.



### Caution

The maximum value at the pressure flow indicator must not exceed 0.4MPa. In case of non-compliance, the tubing or lens may be damaged.

### MAINTENANCE NOTE:

The filters of the Gas-Kit light (maintenance unit) must be checked regularly for liquid formation. This liquid would be blown onto the material, reach the lens and contaminate it.

- Check air pressure preparation!
- Only connect dry and oil-free compressed air.

If you have any questions, please contact our experienced technical support in your area.

### 8.9.6 Temperature sensor

The temperature sensors ensure reliable temperature monitoring of the interior of the machine and are available as additional option.

If a preset temperature value is exceeded, an acoustic alarm continuously sounds to warn the operator of abnormal temperature trends during processing.



### Warning

#### Fire hazard

The acoustic alarm upon startup of the machine indicates that the sensors are operating properly. However, the sensors do not guarantee fire prevention.

- The unit must not operate unattended despite the integrated temperature sensors.
- If the acoustic alarm does not sound when the machine is switched on, check the functionality of the sensors.
- In case of questions, contact our experienced Technical Support in your local area.

## TEMPERATURE SENSOR ALARM ACKNOWLEDGEMENT



Press any key on the keypad to acknowledge the alarm.



### Notice

The signal tone sounds again and again until the temperature returns to normal. Alternatively, switch off the laser system and check the temperature sensors.


### 8.9.7 Vision Design&Position

Camera-supported design and positioning directly on the workpiece live in Ruby®, regardless of whether the lid is closed or open. This permits a true representation of the laser job on the workpiece in the laser software - “What You See Is What You Get” (WYSIWYG). Vision Design&Position is therefore very suitable for small series, and residual materials can be utilized more effectively and easily.



### LIVE IMAGE IN RUBY®

Once the camera has been activated, you will receive a live image of the entire workspace.



**Ruby® allows you to work directly on the workpiece:**

- set a text
- design graphics
- adjust an existing job.




#### Notice

The camera image must be calibrated for each lens distance that is used. This is done in the Ruby laser software settings®

### CIRCULAR POLARIZATION FILTER SETTING

Using the circular polarization filter, you can set a stronger image contrast and suppress distracting reflections and back reflections as required.



- Vision Design&Position must be activated in Ruby®.
- Use the live image to make adjustments.
- Turn the lower ring of the polarizing filter until you have achieved the desired result.

### 8.9.8 Screw feet



The height-adjustable feet are available as an option.

They compensate for unevenness and give the machine better stability.

## 9 Maintenance

### 9.1 Safety notes



#### **Danger**

**Improper maintenance can cause serious injury or damage.**

Maintenance may be carried out only by authorized, trained personnel who are familiar with how to operate the machine and in strict observance of all safety notes.



#### **Danger**

**Risk of fire or explosion.**

Improper handling of the machine may cause fire or explosion.

- For cleaning the machine, do not use explosive or flammable substances or cleaning agents.
- No flammable or explosive liquids may be stored in or near the machine.
- Always keep the system clean, and remove flammable parts from the working area or exhaust area.



#### **Warning Dangerous electrical voltage**

**Danger of electrical shock.**

Work on electrical fittings may be carried out only by qualified personnel and in strict observance of the safety notes.

Before any maintenance work takes place, disconnect the machine from the mains voltage and make sure the system is de-energized.

#### **IMPORTANT NOTE ON MACHINE SAFETY:**



#### **Notice**

The safety devices of the laser system must be replaced due to component aging or corresponding (e.g. > 72,000 lid cycles / anno), the safety equipment of the laser system must be replaced by an authorized technician after 10 years at the latest, otherwise safety can no longer be guaranteed. Without measures, the operating license will expire.

### 9.2 Service life of safety-relevant components

The safety-relevant components have a service life of ten years from the date of initial commissioning.



#### **Notice**

After ten years, an authorized technician must be contacted to check the safety-relevant components and replace them if necessary (e.g. emergency stop, interlock sensors, cover, etc.).

Otherwise, safety is no longer guaranteed due to component ageing and/or frequent actuation.

The operating license expires if the safety-relevant components are not checked.

### 9.3 Maintenance plan

System Components	Daily	Weekly	Half-yearly	Yearly	Chapter
Checking the safety circuit	✓				<a href="#">"Daily inspection of the safety circuits"</a>
Lens, mirror #4	✓✓				<a href="#">"Cleaning the mirrors"</a>
Mirror #2 and mirror #3			✓✓		<a href="#">"Cleaning the mirrors"</a>
Ultrasonic sensor (option)	✓✓				<a href="#">"Ultrasonic sensor (Sonar Technology™)"</a>
Working table and rulers.	✓✓				
Vent slots of exhaust box. (inside the machine)	✓✓				
Entire working area. General cleaning.		✓			
Energy Chain x-axis		✓			
Vent slots (backside of the machine)			✓✓		
Spindles				<b>CG</b>	
Cover of the laser source and housing.		✓			
Operate emergency stop		✓			

✓✓ Check for cleanliness and proper condition, and clean if necessary.

✓ Clean whenever required.

**CG** Clean and grease



#### Notice

In order to ensure the maximum availability and lifetime of the system, we recommend that you regularly check the filter, ventilation and exhaust slots and keep the surrounding area clean. A visual inspection of the lenses is likewise recommended before switching on the system.

### 9.4 Daily inspection of the safety circuits

#### BEFORE STARTING WORK:

##### Checking the safety switch:

1. After initializing, open top cover
  - The LED on the keyboard's Start button should be flashing quickly (2 Hz)

### 2. Close the lid

- The LED on the keyboard's Start button should be flashing slowly (0.5 Hz)

→ Check completed

### Checking the emergency stop button:

#### 1. Press the emergency stop button

- Interior lighting is switched off
- LEDs on the membrane keyboard are switched off
- Axes are freely movable

#### 2. Release the emergency stop button

- Machine must be restarted using the key switch

→ Check completed

## 9.5 Change the filter mat

If it is necessary to change the filter mat, open the power supply cover on the rear of the machine and replace it.



## 9.6 Cleaning

### 9.6.1 Machine

1. Bring the processing table to a position where you find it easy to clean the surface with window cleaning agents and paper towels.
2. Switch off the unit and disconnect it from the mains.
3. Open the acrylic lid and the front lid.
4. Thoroughly remove all loose dirt and deposits from the inside of the machine (e.g. with a brush or vacuum cleaner). To do this, it is necessary to remove the table and the table tray.
5. Clean the air baffle and suction slots of the suction box in the interior with a dry or slightly damp cotton cloth or a brush.
6. Clean the laser tube cover and ventilation slots on the back of the machine with a dry or slightly damp cotton cloth.
7. Clean the safety lid with a dry or slightly damp cotton cloth. Do not use paper towels as these could scratch the acrylic.

### 9.6.2 Optics in general

Trotec Laser GmbH recommends to use the cleaning set enclosed. Alternatively, use high-quality cotton swabs together with the provided cleaning liquid.



#### **Notice**

**The following cleaning products are available as accessory parts:**

- Lens cleaning cloth
- Lens cleaning liquid

### 9.6.3 Lens



#### Warning

##### Damage to optics.

Soiled optics absorb laser radiation and can thus be destroyed. Broken or damaged lenses as well as thermal decomposition of lenses release particles which cause serious damage to the health.

- The passive reflectors and optics in the area of the laser beam guidance should be cleaned regularly.
- Special care is required when handling, attaching and cleaning these elements.
- Do not exert non-uniform pressure.
- Do not use tools or hard objects to clean the surface.
- Never touch the optics with your bare fingers.
- Never use cleaning tissues twice.
- When lenses get broken, damaged or thermal decomposed follow the protective measures.
- Disposal according to regulations and laws valid in the user's country.
- Lenses with scratches or penetrations must not be used anymore.

#### STEP1: PREPARATION

1. Blow away loose particles and dust by means of bellows/bellows or compressed air (according to ISO 8573:2010 class 1).
2. Get the cleaning liquid and cleaning tissues ready.
3. Move the table up and put a cloth under the lens holder (so that the lens will not be damaged if it falls out of holder by accident).
4. Loosen the lens by screwing the clamping ring inward.
5. Now remove the lens and check the surface.



#### STEP 2: CLEANING WITH CLEANING LIQUID AND CLEANING TISSUES

1. Remove the lens and rinse it with cleaning liquid to wash away coarse soiling.
2. Put some cleaning liquid onto the lens and leave the liquid for 1 minute to take effect.
3. Soak a cleaning tissue with cleaning liquid and carefully wipe off the surface.
4. Now carefully insert the lens with the lens holder into the laser head and fixate the clamping ring.



### Notice

Trotec Laser GmbH recommends to use the following cleaning products, which are available as accessory parts:

Lens cleaning cloth (part number 69249) and lens cleaning liquid (part number 69248).

## 9.6.4 Cleaning the mirrors




### Caution

Make sure that you do not touch the mirror with your fingers, since this would greatly reduce the service life of the mirror.

Do not touch the mirror with your fingers or with tools, and never use a cleaning tissue twice, as the surface could easily be scratched.

### CLEANING THE MIRRORS #2 AND #3




SpiMirror #3

1. For cleaning of mirrors #2 and #3, you must first remove the right maintenance panel.
2. Do not remove the mirror #2. It must remain in the machine for cleaning.
3. The mirror #3 is attached by means of two Allen screws (1), which are located on the mirror holder. Open the screws and remove the lens holder together with the mirror.

#### **Do not touch the milled screws (2) while doing this!**

4. Flush the mirror with cleaning liquid to wash away coarse soiling.
5. Put some cleaning liquid onto the mirror and leave the liquid for 1 minute to take effect.
6. Soak a cleaning tissue with cleaning liquid and carefully wipe off the surface.
7. Now carefully put back the mirror and fixate it with the two Allen screws.

### CLEANING THE MIRROR #4



1. While holding the mirror, loosen the two knurled screws (1) and lift the mirror from the mirror holder.



#### Caution

Make sure that the mirror does not grind over the mirror holder, as it can be scratched very easily.

2. Flush the mirror with cleaning liquid to wash away coarse soiling.
3. Put some cleaning liquid onto the mirror and leave the liquid for 1 minute to take effect.
4. Soak a cleaning tissue with cleaning liquid and carefully wipe off the surface.
5. Now carefully re-insert the mirror and fixate it with the two knurled screws.

Mirror #4

### 9.6.5 Ultrasonic sensor (Sonar Technology™)



The sensor can either be cleaned with a brush or wiped with a dry or damp microfiber or anti-static cloth using a gentle cleaning fluid. An isopropanol or ethanol solution can be used for stubborn dirt.

However, this should not be allowed to soak in or used in the long term (over several months or years).

## 10 Troubleshooting

This chapter should enable the maintenance personnel to identify and resolve operational faults based on error messages and symptoms.



### Warning

#### Risk of fire from incorrect parameter settings.

Laser operation with incorrect parameter settings such as power settings, speed or frequency can result in flame formation.

- Laser operation permitted only under supervision.



### Caution

System failures that cannot be remedied can cause damage to the machine.

- Disconnect the machine from the mains and contact your local Technical Support.

### 10.1 Error, cause and remedy

Problem	Possible cause	Remedy
<b>Too low engraving depth.</b>	<ul style="list-style-type: none"> <li>• Imprecise focusing.</li> <li>• Dirty optics.</li> </ul>	<ul style="list-style-type: none"> <li>• Check focus.</li> <li>• Clean optics.</li> </ul>
<b>Blurred edges.</b>	<ul style="list-style-type: none"> <li>• Imprecise focusing.</li> </ul>	<ul style="list-style-type: none"> <li>• Check focus.</li> </ul>
<b>Missing cut lines.</b>	<ul style="list-style-type: none"> <li>• Zero passes in material database.</li> <li>• Line thickness in CorelDraw too big.</li> <li>• Color was skipped in the software.</li> </ul>	<ul style="list-style-type: none"> <li>• Increase the amount of passes in the material database.</li> <li>• Reduce line thickness to the smallest possible value.</li> <li>• Set color to cutting in the database.</li> </ul>
<b>Waviness of the lines.</b>	<ul style="list-style-type: none"> <li>• Lens is loose.</li> </ul>	<ul style="list-style-type: none"> <li>• Check lens and lens holder.</li> </ul>
<b>No visible marking result.</b>	<ul style="list-style-type: none"> <li>• Too low laser power.</li> <li>• Too high speed.</li> <li>• Not focused.</li> <li>• Wrong focus tool.</li> </ul>	<ul style="list-style-type: none"> <li>• Increase power setting.</li> <li>• Reduce speed.</li> <li>• Check focus.</li> <li>• Change focus tool.</li> <li>• When using autofocus, check the settings within the software (lens, material thickness, table).</li> </ul>
<b>Fine details on stamps are engraved too thinly.</b>	<ul style="list-style-type: none"> <li>• Too steep shoulders.</li> </ul>	<ul style="list-style-type: none"> <li>• Choose other shoulder or edit (flat/medium/steep): Options/Process Options/Stamp.</li> </ul>

Problem	Possible cause	Remedy
<b>The size to be engraved or cut does not match the size in CorelDraw.</b>	<ul style="list-style-type: none"> <li>• Raster correction ON in the software.</li> <li>• Wrong size settings in the printer driver.</li> <li>• Wrong image position is selected in the layout tab (printing).</li> <li>• Wrong machine is selected in the software.</li> </ul>	<ul style="list-style-type: none"> <li>• Switch off raster correction in the software (settings/advanced options/laser tab).</li> <li>• Use the same size as in CorelDraw.</li> <li>• Switch the layout settings to: as in document.</li> <li>• Select the proper machine in the software.</li> </ul>
<b>Corners and angles are not cut or marked.</b>	<ul style="list-style-type: none"> <li>• Power too low.</li> </ul>	<ul style="list-style-type: none"> <li>• Increase the correction in the software (Settings / Material Templates Setup - Correction).</li> </ul>
<b>No referencing after commissioning.</b>	<ul style="list-style-type: none"> <li>• Top, front or side door not closed.</li> </ul>	<ul style="list-style-type: none"> <li>• Close doors.</li> </ul>
<b>No response upon switching on of the system.</b>	<ul style="list-style-type: none"> <li>• Fuse blown.</li> <li>• No electric power at power outlet.</li> </ul>	<ul style="list-style-type: none"> <li>• Check fuses.</li> <li>• Check power outlet.</li> </ul>
<b>No communication with machine.</b>	<ul style="list-style-type: none"> <li>• Invalid COM port selection.</li> <li>• Communication cable defect.</li> <li>• COM: port is in use by another program.</li> </ul>	<ul style="list-style-type: none"> <li>• Change selection.</li> <li>• Check cable.</li> <li>• Close this program, or change the COM port.</li> </ul>
<b>Connection to machine frequently interrupted.</b>	<ul style="list-style-type: none"> <li>• Electromagnetic emissions.</li> </ul>	<ul style="list-style-type: none"> <li>• Make sure that machine and computer are connected to the same electric circuit; the original cable lengths should not be exceeded.</li> </ul>
<b>Offsets between engraving jobs and cut lines.</b>	<ul style="list-style-type: none"> <li>• Speed too high.</li> </ul>	<ul style="list-style-type: none"> <li>• Reduce speed.</li> </ul>
<b>Errorcode 124</b>	<ul style="list-style-type: none"> <li>• Interlocks open during the referencing process.</li> </ul>	<ul style="list-style-type: none"> <li>• Restart the machine (key switch).</li> </ul>
<b>Other faults.</b>		<ul style="list-style-type: none"> <li>• Contact Technical Support.</li> </ul>

## 11 Contact details

### TECHNICAL SUPPORT

In case of questions, contact our experienced Technical Support in your local area.

For global service contact numbers and further information please see our website, section "Support":  
**[www.troteclaser.com](http://www.troteclaser.com)**

When you call, stay close to the machine and have the following information to hand (see "[answer form](#)"):

- At which working process did the problem occur?
- What you have done so far to correct the problem.
- Serial number (see "[Type plate](#)").
- Error code.

### LOCAL OFFICES / SALES

Our store locator and detailed information on our offices in your area can be found on our website in section "Contact", "Local Office": **[www.troteclaser.com](http://www.troteclaser.com)**

### TECHNICAL DOCUMENTATION

For feedback or to suggest changes to this manual, contact:

Technical documentation: +43 (0) 7242 239 - 7000

E-Mail: **[technical.documentation@troteclaser.com](mailto:technical.documentation@troteclaser.com)**

### 12 Disassembly



#### **Warning**

##### **Danger of injury when disassembling the machine.**

There is danger of injury when disassembling the machine.

Always wear suitable protective clothing (e.g. safety goggles, safety shoes, safety gloves).



#### **Warning Dangerous electrical voltage**

##### **Electric current.**

The machine must be disconnected from the main power supply.



#### **Notice**

- Always use suitable tools to disassemble the machine.
- Mind the springs.
- Follow chapter "Disposal".

#### **PROCESS:**

1. Remove all workpieces from the system.
2. Turn the key switch to switch off the machine.
3. Switch off the main switch at the back of the machine.
4. Remove the exhaust system.
5. Disconnect all cables at the back of the machine.

## 13 Disposal



### **Disposal**

#### **Do not dispose of the machine with domestic waste!**

Electronic devices have to be disposed of according to the regional directives on electronic and electric waste disposal.

In case of further questions, please ask your supplier.

In case of disassembly, use suitable tools to dismantle the unit into individual parts. Sort the individual parts and have them disposed of professionally. Legal regulations must be adhered to.

14 Appendix

# Acceptance report



Dear customer!

We request your confirmation of properly completed transfer of the machine. Please transmit a copy of this document - filled out and signed by an authorized company representative - to an employee of our sales affiliate for forwarding to the manufacturer.

Please check applicable items:

- Machine parts checked for shipping damage.
- Machine parts checked against delivery note.
- Setup of the machine discussed.
- Startup of the machine discussed.
- Operation of the machine discussed.
- Maintenance of the machine discussed.
- Electrical voltage checked.
- Safety notes discussed.
- Trial run performed.
- Deficiencies determined.

The machine with the machine designation:

has been checked according to the listed items and has been handed over properly.

\_\_\_\_\_  
City, Date

\_\_\_\_\_  
(Instructed person)  
Name, Position

\_\_\_\_\_  
Company stamp, Signature

## Training verification form

Trainee: \_\_\_\_\_

Trainer: \_\_\_\_\_

Date of Training: \_\_\_\_\_

The employee named above was instructed in the operation of the .....  
laser system. Especially the following topics were covered:

- Machine function
- Danger areas
- Warnings
- Position of the Emergency stop button
- Personal protective equipment
- Operating equipment
- Workflow
- Setting-up
- Startup and Shutdown
- Reporting of unexpected working results and actions to be taken.
- Reporting of failure and actions to be initiated.
- Responsibility for troubleshooting.
- Operating manual and it's storage location for inspection.

\_\_\_\_\_  
Signature Trainer

\_\_\_\_\_  
Signature Trainee



## Response form

Dear customer!

In case of any trouble with the machine, please provide the following information and additionally create a service file.

### Contact details

Name: \_\_\_\_\_  
Country: \_\_\_\_\_  
Phone: \_\_\_\_\_  
E-mail: \_\_\_\_\_  
Date: \_\_\_\_\_

### Machine data

Serial number: \_\_\_\_\_  
Layout Software: \_\_\_\_\_

Description of the problem

Does an error message show up on the PC , and if so, which?

What happened before the error occurred? (Thunder and lightning, Windows-Update...)

What attempts were made to solve the problem?

Please send the information to your sales representative, to your local support or to following e-mail address: [techsupport@troteclaser.com](mailto:techsupport@troteclaser.com).

## 15 Acronyms

Acronym	Description
AC	Air cooled
AC	Alternating current
API	Application programming interface
BAT	Beam alignment tool
CAT	Category
CCL	Critical closed loop
CE	European Conformity
CO <sub>2</sub>	Carbon dioxide
COM	Communication
CPU	Central processing unit
dB(A)	A-weighted decibel
DC	Direct current
DGUV	Deutsche Gesetzliche Unfallversicherung (German Statutory Accident Insurance)
DHCP	Dynamic host configuration protocol
DIN	Deutsches Institut für Normung (German Institute of Standardization)
DNS	Domain name system
I/O	Input/output
EC	European Community
EMC	Electromagnetic compatibility
EN	European standard
GPU	Graphical processing unit
HD	High definition
IEC	International Electrotechnical Commission
IP	Ingress protection
IP	Internet protocol
ISO	International Organization for Standardization
LAN	Local area network
LASER	Light amplification from stimulated emission of radiation
LC	Liquid cooled
LED	Light emitting diode
MPC	Maximum permissible concentration
MPR	Maximum permissible radiation

Acronym	Description
NW	Nominal width
OEM	Original equipment manufacturer
OPC UA	Standard for data exchange as platform-independent, service-oriented architecture (Open platform communications)
Pa	Pascal (printing unit)
PC	Personal computer
PCB	Printed circuit board
PIN	Personal identification number
RAM	Random access memory
RFID	Radio frequency identification
SONAR	Sound navigation and ranging
T	Time delay (slow release)
TPU	Tensor processor
URL	Uniform resource locator
USB	Universal serial bus
UV	Ultraviolet
VDI	Verein deutscher Ingenieure (Association of German Engineers)
VDP	Vision Design&Position
W	Watts
WC	Water cooled
Wifi	Wireless network
WLAN	Wireless local area network
WTK	Water treatment kit
ZnSe	Zinc selenide

## Speedy 360

Laser engraving system

### Mechanics

Working area	813 x 508 mm (32 x 20 inch)
Loading area standard	890 x 600 mm (35 x 23.6 inch)
Max. height of work piece	210 mm (8.2 inch) with 1.5 inch, 2.0 inch lens 197,5 mm (7.7 inch) with 2.0 inch clearance lens, 2.5 inch lens 159 mm (6.2 inch) with 4.0 inch 146,5 mm (5.7 inch) with 4.0 inch clearance lens
Working table	Multifunctional table concept, Rulers in mm or inches Electronic, programmable Z-axis with servo motor
Max. processing speed	355 cm/s (140 ips)
Acceleration	50 m/s <sup>2</sup> (1969 ips <sup>2</sup> )
Motors	Brushless DC servo motors
Encoder	Incremental measuring system
Optical elements	Telescope, mirrors, lens
Lens	1.5 inch, 2.0 inch, 2.0 inch clearance, 2.5 inch, 4.0 inch, 4.0 inch clearance
Accuracy	+/- 0.015 mm (0.0006 inch), over the whole working area
Addressable accuracy	5 µm (0.0002 inch)
Accuracy to size of parts	According to material and process
Maximum material load	Static: up to 100kg (220 lbs), Dynamic: up to 30 kg (66 lbs) load over the whole working area
Interface	Ethernet, optional Wifi

### Features standard

Lens	2.0 inch
InPack Technology™	Protects working head and all moving parts from dust
Exhaust	Surface exhaust via rear of the engraving cabinet, table exhaust with vacuum and cutting tables
Software	Ruby®
Operating console	Touch panel, keypad, safety-switch, system turnkey
Table	Aluminum cutting grid table
Laser Pointer	655 nm, <0,99 mWcw
Autofocus	Sonar Technology™ and software
Work area light	LED
Additional standard features	Ergonomic access to working area, OptiMotion™, coaxial air assist incl. integrated pump, harsh environment protection kit, integrated extraction slits, two Z-Home positions, air-assist nozzles (Ø3mm and Ø7 mm), lockable casters

## Options

Vision Design&Position	Design and Position job in live view of work area on Ruby screen.
Temperature sensor	Should the temperature inside the engraving compartment exceed a critical value, the system will signal this to the operator by a warning sound. The operator then can take action immediately.
Gas-Kit light	Control of external supplied compressed air (free of mechanical dust, water and oil) max. flow rate 150 l/min (40 gpm) with max. 10 bar (145 psi);
Water cooling preparation	Additional parts to connect an external cooler
Screw feet	Additional to the rolls, for a good standing on the ground
Industrial interface	Start / Stop / ... signals to control the operation from extern

## Accessories

Vision Print&Cut	Registration marks detection and compensation system Max. working area without camera: 813 x 508 mm (32 x 20 inch) Max working area with camera: 801 x 508 mm (31.5 x 20 inch)
Ferromagnetic engraving table	Allows to mount thin materials such as paper, films or foils with magnets to ensure an even and flat surface to achieve optimal results
Vacuum table	Vacuum effect for fixation of thin or wavy materials
Acrylic cutting grid table (white)	Reflection free cutting of parts smaller than 100 mm (4 inch)
Slat cutting table	Cutting of thicker materials and parts bigger than 100 mm (4 inch); removable aluminium and acrylic slats, x-axis ruler can be removed and mounted again without re-adjustment
Honeycomb cutting table	Good compromise between the Grid and Slat table configuration. Thin support structures reduce flashback compared to a grid table. High density of the honeycomb structure provides good support for less rigid material such as thin plastic, card & paper or membrane boards; nominal comb size 12,7 mm (0.5 inch) or 6,4 mm (0.25 inch)
Rotary attachment	Cone, roll or combined version, tilt able Max. workpiece length cones: 550 mm (21.6 inch) Max. workpiece length rolls: $\varnothing \geq 58$ mm (2.2 inch) = 679 mm (26.7 inch), $\varnothing \leq 58$ mm (2.2 inch) = 745 mm (29.3 inch) Max. workpiece diameter cones: 207 mm (8.1 inch), depending on lens Max. workpiece diameter rolls: 96 mm (3.7 inch), depending on lens
TroCare	Comprehensive package of technical services

## Laser

Laser system CO <sub>2</sub>	Sealed-off laser, maintenance free, air cooled, wavelength 10.6 $\mu$ m 60, 80, 100 and 120 W
------------------------------	--

## Dimensions & weight

Width x Depth x Height	1221 x 830 (790*) x 1066 mm (48 x 32.8 (30.7*) x 42.0 inch) * top lid closed, without mounted exhaust hose connections, gas-kit light
Weight	Approx. 235 – 250 kg / 518 - 551 lbs (depending on laser power)

## Safety & environment

Laser class	CDRH laser class 2
Interlock	Safety system with Individually checked Interlocks, optional with Dual-coded interlocks
Ambient conditions	Mandatory ambient temperature +15° to +25° C or 59° to 77° F Humidity 40% to max. 70%, not condensing Dust free environment (2nd degree according to IEC 60947-1)
Certificates	CE compliant, FDA listed

## Exhaust

Minimum volume required (without piping/tubing)	350 m <sup>3</sup> /h at 3.500 Pa Two connections
Required	Atmos Duo Plus (or equivalent systems, all table concepts) Vent Set 400 (or equivalent systems; all table concepts except vacuum table/strong vacuum effect) Vent Set 500 (or equivalent systems, all table concepts incl. vacuum table/strong vacuum effect)

## Cooling

Air cooling	Active air flow cooling with fan
Liquid cooling	Optional available for CO <sub>2</sub> laser sources 60 – 120 watts with external liquid cooler

## Electrical

Voltage & power consumption	1 ~ AC 110-230V 50/60Hz, approx. 1200 W to 1900 W (depending on laser power)
-----------------------------	--

Subject to change without notice. Errors and omissions reserved.

Model identification Speedy 360C-8085

October 2023

# EC-Declaration of Conformity

According to Machine Directive 2006/42/EC, Annex II 1. A

# trotec

## Manufacturer:

Trotec Laser GmbH  
Freilinger Straße 99  
4614 Marchtrenk  
Austria

## Authorized person to compile the technical files:

Trotec Laser GmbH  
Freilinger Straße 99  
4614 Marchtrenk  
Austria

## Description and Identification of the machine:

Product description	Laser cutting and engraving system
Model name	Speedy 360 , Speedy 360 flexx , Speedy 400 , Speedy 400 flexx
Model identification	Speedy 360C-8085 , Speedy 360X-8085 , Speedy 400C-8086 , Speedy 400X-8086
Serial number	S4-7### , X4-7###
Machine group	8085 , 8086
Function	System for laser cutting and laser engraving

## It is declared expressly that the machine fulfills all of the following applicable EC directives and regulations:

2006/42/EC	EC Machine Directive 2006/42/EC
2014/30/EU	Directive 2014/30/EU Electromagnetic Compatibility

## Reference to the harmonized standards in accordance with article 7 (2):

ISO 11553-1:2020	Safety of machinery – Laser processing machines Part 1: General safety requirements
ISO 12100:2010	Safety of machinery – General principles for design – Risk assessment and risk reduction
ISO 13849-1:2018	Safety of machinery – Safety related parts of control systems Part 1: General principles for design
IEC 60204-1:2018	Safety of machinery – Electrical equipment of machines Part 1: General requirements
IEC 60825-1:2022	Safety of laser products - Part 1: Equipment classification and requirements
IEC 61000-3-2:2019	Electromagnetic compatibility - Part 3-2: Limits for harmonic current emissions
IEC 61000-3-3: 2013 +A1:2019	Electromagnetic compatibility - Part 3-3: Limitation of voltage changes / fluctuations and flicker
IEC 61000-6-2:2019	Electromagnetic compatibility - Part 6-2: Immunity standard for industrial environments
IEC 61000-6-4:2019	Electromagnetic compatibility - Part 6-4: Emission standard for industrial environments

## Further Reference to the harmonized standards in accordance with article 7 (2):

IEC 60825-4:2012	Safety of laser products - Part 4: Laser guards
------------------	---

Marchtrenk, 14 November 2023

City, Date

# trotec

Trotec Laser GmbH  
Freilinger Strasse 99, A-4614 Marchtrenk  
T +43 7242 239-0  
[www.troteclaser.com](http://www.troteclaser.com)

pp. Hagen Strasser  
Head of Research and Development