

External components



1. Touch screen command panel
2. Emergency button
3. Tank cover
4. Magnetic filter
5. Unload cleaning point
6. Front panel
7. Swivelling wheels