


PA 800-17 Pallet Aligner

Instruction usage


Step 1.

Drive into the pallet aligner with the stack.



Step 2.

The bottom of the stack is now aligned. It depends on pallet fork frame how many pallets it will fix. Do it as many times it takes to align the pallet stack.



Step 3.

Take the aligned stack and drive away.

