



RICO - Tomás Castro Silva, Lda.

Shears - Press Brakes

Portugal

4515-118 Gondomar
Rua de Cerquido, Zebreiros
Phone. +351224540370
Fax +351224541424
e-mail geral@rico.pt

Customer
Street
ZIP code / City
Phone
Fax
e-mail

end customer
Street
ZIP code / City
Phone
Fax
e-mail

Project name	PRCx 6x FPSC 2014V6.0.2_Pedestal
Project description	PRCB 30100 SN2390 DA-66T X, R, AKAS II-M, RICO CROWNING
Commission	RICO
Responsible for project	Marcílio Silva
Created on	2014
Project end	
Edit date	15-06-2016
by (short name)	marcilio.silva
Number of pages	112


Place of installation	
Manufacturer (company)	Tomás Castro Silva, Lda.
Make	
Part feature	
Input wiring	E+3PH 4G4mm ²
Power supply	400 V AC 50 Hz
Control voltage	24 V
Rated current	15 A
Regulations	Directive 2006/42/CE;EN 12622:2009 2006/95/CE;2006/42/CE;2009/125/CE
Enclosures	
Degree of protection	IP 66 ; IK 10

Directive: EU																						
General information: PRCx 6x FPSC 2014V6.0.2_Pedestal This electrical schematic is provided with the referenced machine as the appropriated documentation, it shall not be reproduced or distributed without RICO consent.																						
Specific regulations Directive 2006/42/CE European standard EN 12622:2009 Directive 2006/95/CE Directive 2009/125/CE European standard EN 12622	Documentation regulations IEC 60364 EN 61355 DIN EN 60617 DIN EN 61082	Technical drawing regulations EN 60204 EN 60529 EN 61557 IEC 60364																				
Safety systems: FIESSLER FPSC (CAT IV) FIESSLER AKAS-3 (CAT IV) PILZ PSEN (CAT IV)																						
Machine options <table><tr><td>Y1 + Y2</td><td>☐</td><td>SPA</td><td>☐</td></tr><tr><td>X Axis</td><td>☐</td><td>ACF1</td><td>☐</td></tr><tr><td>R Axis</td><td>☐</td><td>CROWNING</td><td>☐</td></tr><tr><td>X5 Axis</td><td>☐</td><td>CLAMPING</td><td>☐</td></tr><tr><td>Z1 + Z2 Axis</td><td>☐</td><td></td><td></td></tr></table>		Y1 + Y2	☐	SPA	☐	X Axis	☐	ACF1	☐	R Axis	☐	CROWNING	☐	X5 Axis	☐	CLAMPING	☐	Z1 + Z2 Axis	☐			Note This schematic is presented with all the machine options, so as all listings and documentation group all the components required for all options.
Y1 + Y2	☐	SPA	☐																			
X Axis	☐	ACF1	☐																			
R Axis	☐	CROWNING	☐																			
X5 Axis	☐	CLAMPING	☐																			
Z1 + Z2 Axis	☐																					
Note:																						

Table of contents

Column X: An automatically generated page was edited F06_001

Page	Page description	supplementary page field	Date	Edited by	X
/1	Cover page		03-03-2016	marcilio.silva	X
/2	General information		03-03-2016	marcilio.silva	X
/3	Table of contents : /1 - =EDM+MCBN/15		15-06-2016	marcilio.silva	
/3.1	Table of contents : =EDM+MCBN/16 - =EDM+MCBN/45		29-04-2016	marcilio.silva	
/3.2	Table of contents : =EDM+MCBN/46 - =REPORT/28		15-06-2016	marcilio.silva	
/3.3	Table of contents : =REPORT/29 - =REPORT/41		15-06-2016	marcilio.silva	
=TDM1+EPC1/1	PRCN Structure identifier layout		03-03-2016	marcilio.silva	
=TDM1+EPC1/2	Cabinet layout Note:Layout may differ according to the optionals		03-03-2016	marcilio.silva	
=TDM1+EPC1/3	Pedal 1 layout		03-03-2016	marcilio.silva	
=TDM1+EPC1/3a	Pedal 1 layout		03-03-2016	marcilio.silva	
=TDM1+EPC1/4	Pedal 2 layout		03-03-2016	marcilio.silva	
=TDM1+EPC1/5	Pedestal socket layout		03-03-2016	marcilio.silva	
=TDM1+EPC1/6	Terminal Blocks structure identifier layout		03-03-2016	marcilio.silva	
=TDM1+EPC1/7	Structure identifier overview		03-03-2016	marcilio.silva	
=EDM+MCBN/1	Power supply		15-06-2016	marcilio.silva	
=EDM+MCBN/1a	Power supply		15-06-2016	marcilio.silva	
=EDM+MCBN/2	Power supply		18-03-2016	marcilio.silva	
=EDM+MCBN/2a	Power supply		03-03-2016	marcilio.silva	
=EDM+MCBN/3	Drives 1		18-03-2016	marcilio.silva	
=EDM+MCBN/4	Drives 2		18-03-2016	marcilio.silva	
=EDM+MCBN/5	Drives 3		18-03-2016	marcilio.silva	
=EDM+MCBN/6	Pedal light connections		18-03-2016	marcilio.silva	X
=EDM+MCBN/7	24VAC Control		18-03-2016	marcilio.silva	
=EDM+MCBN/7a	24VAC Control		10-05-2016	marcilio.silva	
=EDM+MCBN/7b	24VAC Control		21-03-2016	marcilio.silva	
=EDM+MCBN/8	24VAC Control		18-03-2016	marcilio.silva	
=EDM+MCBN/9	24VDC		18-03-2016	marcilio.silva	
=EDM+MCBN/10	24VDC		18-03-2016	marcilio.silva	
=EDM+MCBN/11	DNC Modules		23-03-2016	marcilio.silva	
=EDM+MCBN/12	DNC Modules		18-03-2016	marcilio.silva	
=EDM+MCBN/13	FPSC-B-C-S		18-03-2016	marcilio.silva	
=EDM+MCBN/14	Hydraulic pump start/stop		15-06-2016	marcilio.silva	
=EDM+MCBN/15	Hydraulic proportional valves control		18-03-2016	marcilio.silva	



1				2a			
				= TDM1 + EPC1			
Modification				Page 2			
Date				Total pages 10			

1				2			
				= TDM1 + EPC1			
Modification				Page 2			
Date				Total pages 11			

PEDAL LAYOUT

TOP VIEW


NOTE: ONLY VALID WHEN THE MACHINE HAS TWO PEDALS!

BOX REQUEST

UP



SOCKET

-6X0




LED Strip

- 386 → RED
- 387 → GREEN
- 388 → BLUE
- 24VDC → WHITE




EMERGENCY STOP

-32S7



-31S5

-31S3





SECOND OPERATOR FOOT-PEDAL LAYOUT

TOP VIEW

UP


SOCKET

-6X5



LED Strip

- 386 → RED
- 387 → GREEN
- 388 → BLUE
- 24VDC → WHITE



A

B

C

D

E

Page	5
Total pages	112

Double-deck terminal block




Simple terminal block



Example 1

-7X2
terminal block 3




Example 2

-5X5
terminal block 1




Example 3


-1X2
terminal block 4




schematic




schematic




schematic







=TDM1+EPC1/7

				Date	15-06-2016	RICO	Power supply			= EDM	
				Ed.	marcilio.silva					+ MCBN	
				Appr		PRCB 30100 SN2390 DA-66T				Page	1
	Modification	Date	Name	Original		X, R, AKAS II-M, RICO CROWNING					Total pages112










Rico Led TechBar


(OPTIONAL)





2a




















RICO CROWNING
CONTROL
CONNECTIONS
(OPTIONAL)



(ALL OPTIONAL AXIS)







- 1

2

/5.2
- 3

4

/5.3
- 5

6

/5.3
- 1

2

/5.6
- 3

4

/5.7
- 5






6

/5.7

ACF1 LEFT AXIS
POWER
CONTACTOR
COIL

ACF2 RIGHT AXIS
POWER
CONTACTOR
COIL

(OPTIONALS)



WILLA HYDRAULIC CLAMPING
(OPTIONAL)

LEFT ACF RSD

RIGHT ACF RSD


(OPTIONALS)


CLAMPING ORDER
FROM CONTROLLER

TOOL CLAMP
CONTROLLER FEEDBACK


TOOL CLAMP
VALVE

TOOL RELEASE
VALVE













I / O CONNECTOR



I / O CONNECTOR



-11A3-X3 /11.4	PUMP	FAST CLOSING ↓↓	MUTE ADJUST	T (TANDEM)	CNC READY	LOWER DEAD POINT ↓	BOX MODE ↓	2ND MUTE ↓↓	
0 V	IN 24	IN 23	IN 22	IN 21	OUT 20	OUT 19	OUT 18	OUT 17	24 V
-	8	7	6	5	4	3	2	1	+



-18W2
LITYCY FLEX
12x0,25

BU BN PK GY WH VT BK GN YE RD

-18X2 1 2 3 4 1 4 1 4 1 2 4 3 5 3 6 4 3 3 1 4 2 1 5 2



0VDC 320 322 447 324 404 449 24VDC




-6X1 1 4

-9X1 1 5

17.9 / 24VDC 17.9 / 0VDC 17.9 / 0VDC.S 24VDC / 19.0 0VDC / 19.0 0VDC.S / 19.0



PUMP 36.9 FASTDOWN 35.4 MUTE_ADJUST 38b.6 C.LOCK 31.7 BOX_MODE 38.2 MUTE 2 38b.6

Only for AKAS 3P






Only for AKAS 3P

I / O CONNECTOR





(OPTIONAL)

RINPOSITION
42.5





I / O CONNECTOR





(OPTIONAL)

PLC-RSC-24DC/21
14 11 /43.2
11 12



I / O CONNECTOR




(OPTIONAL)





I / O CONNECTOR



(OPTIONAL)





I / O CONNECTOR



(OPTIONAL)





I / O CONNECTOR




(OPTIONAL)











(OPTIONAL)























AKAS 24V Versorgungsspannung
AKAS 24V power supply

AKAS SGO Signal

AKAS FUO Signal

Schleichanganforderung an NC
Slow speed request to NC


Befehl St"áuel auf an NC
Beam open command to CN


Meldeleuchte
Indicator overrun

Quittierung hintere Schutzabsicherung
Restart backside guarding


Quittierung Not-Halt
Restart Emergency Stop


Laser Ok




















(OPTIONAL)




(OPTIONAL)


MALE D 9 PIN



(OPTIONAL)


MALE SUB-D 9 PIN







(OPTIONAL)

MALE D 9 PIN



MALE SUB-D 9 PIN



(OPTIONAL)

Parts list

F01_001

Device tag	Quantity	Designation	Type number	Supplier	Part number
=EDM+MCBN-2AF0	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-2AF1	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-1F0	2	Fuse Holder	Fuse Holder	SE	SE.DF143C
=EDM+MCBN-1F5	2	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-1F6	2	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-1F7	2	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-1F8	2	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-1F8.1	2	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-1F8.1	2				FUSE5x20-2A
=EDM+MCBN-1F9	2	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-1F9.1	2	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-1F9.1	2				FUSE5x20-2A
=EDM+MCBN-2F0	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-2F0.1	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-2F1	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-2F1.1	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-2F2	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-2F2.1	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-2F3	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-2F3.1	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-2F4	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-2F5	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-2F8	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-2F8	1				FUSE5x20-2A
=EDM+MCBN-2F9	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-2F9	1				FUSE5x20-2A
=EDM+MCBN-3F0	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-3F1	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-3F3	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-3F4	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-3F6	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-3F7	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-4F0	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-4F1	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-4F3	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-4F4	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-5F2	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-5F3	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-5F4	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-5F6	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-5F7	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-5F8	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-13F3	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-13F3.1	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-13F4	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-13F5	1	Fuse terminal block	2002-1611	WAGO	WAGO.2002-1611
=EDM+MCBN-1Q2	2	thermal overload relay for motor TeSys	LRD21	SE	SE.LRD21
=EDM+MCBN-1Q6	2	thermal overload relay for motor TeSys	LRD32	SE	SE.LRD32

2.1

Pos	Code name	designation	Quantity	Remark
	LAPP.0034504	UNITRONIC LIYCY 4x0,34	2	
	LAPP.0034412	UNITRONIC LIYCY 12x0,25	3	
	LIYCYFLEX4x0,25	Flexible control cable 4x0,25	2	
	H05W-F 3G1,00	Power cable H05W-F 3G1,00	3	
	LAPP.0034603	UNITRONIC LIYCY 3x0,5	1	
	GIVIMISURE.8PM04/SCG2-C86		1	
	GIVIMISURE.8PM07/SCG2-C86		1	
	WAGO.2006-1201	2-CONDUCTOR THROUGH TERMINAL BLOCK	18	CENTRE-/ LATERAL MARKING
	WAGO.2006-1207	2-CONDUCTOR EARTH TERMINAL BLOCK	19	CENTRE-/ LATERAL MARKING
	WAGO.2002-2201	DOUBLE DECK TERMINAL BLOCK	337	THROUGH/THROUGH
	WAGO.2004-1207	2-CONDUCTOR EARTH TERMINAL BLOCK	33	CENTRE-/ LATERAL MARKING
	WAGO.2002-2211/1000-0411	DOUBLE DECK DIODE TERMINAL BLOCK	11	CENTRE MARKING
	HAR.09120032774	HAN-BRID RJ45 PASAMUROS	1	
	WAGO.2002-2221/1000-0434	DOUBLE DECK LED TERMINAL BLOCK	3	CENTRE MARKING
	Green5mmLED	Green 5mm LED	2	
	SE.ZB6-22B	NC BLOCK	1	
	SE.ZB6-25B	NO-NC BLOCK	1	
	AKAS-LC-II-M		1	
	GIVIMISURE.PBSHR5200220 05VL M0.5/S CG1		2	
	PSEN OP4H-S-30-090/1	Light Barrier	1	

Cable name =EDM+MCBN-2AW1			Cable type LIYCY FLEX					
Function text			No. of conductors 12			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/11.1	+NMC1-11A0-COM2	3	BU	+LED-2AU1	TX	/2a.2	
	/11.1	+NMC1-11A0-COM2	2	PK	+LED-2AU1	RX	/2a.2	
	/11.1	+NMC1-11A0-COM2	5	YE	+LED-2AU1	GND	/2a.2	
Cable name =EDM+MCBN-W1			Cable type DK-HSB-RJ45-05					
Function text			No. of conductors			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/11.8	-11A8	HSB_H		-12A1	HSB_H	/12.1	
	/11.8	-11A8	GND		-12A1	GND	/12.2	
	/11.9	-11A8	HSB_L		-12A1	HSB_L	/12.2	
Cable name =EDM+MCBN-1W0			Cable type H07					
Function text			No. of conductors 4G			Cross-section 16		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/1.0	-1X0	1:2	L1	L1		/1.0	
	/1a.0	-1X0	1:2	L1	L1		/1a.0	
	/1.0	-1X0	2:2	L2	L2		/1.0	
	/1a.0	-1X0	2:2	L2	L2		/1a.0	
	/1.0	-1X0	3:2	L3	L3		/1.0	
	/1a.0	-1X0	3:2	L3	L3		/1a.0	
	/1.1	-1X0	4:2	PE	PE		/1.1	
	/1a.1	-1X0	4:2	PE	PE		/1a.1	
Cable name =EDM+MCBN-1W5			Cable type LIYCY					
Function text			No. of conductors 4			Cross-section 1,5		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
				1				
				2				

Cable name =EDM+MCBN-1W5			Cable type LIYCY					
Function text			No. of conductors 4			Cross-section 1,5		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
				3				
				GNYE				
	/1.6	+MSB1-1X6	1	BN	-1X6	3:2	/1.6	
	/1a.6	+MSB1-1X6	1	BN	-1X6	4:2	/1a.6	
	/1.6	+MSB1-1A5	PE	GN	-1X6	1	/1.6	
	/1a.6	+MSB1-1A5	PE	GN	-1X6	1	/1a.6	
	/1.6	+MSB1-1X6	3	WH	-1X6	4:2	/1.6	
	/1a.6	+MSB1-1X6	3	WH	-1X6	3:2	/1a.6	
	/1.6	+MSB1-1X6	2	YE	-1X6	2:2	/1.6	
	/1a.6	+MSB1-1X6	2	YE	-1X6	2:2	/1a.6	
Cable name =EDM+MCBN-2W4			Cable type					
Function text			No. of conductors			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
				1				
				2				
				GNYE				
	/2.4	-2X4	1:1	WH	+LGTR-2H4	x1	/2.4	
	/2.5	-2X4	2:1	WH	+LGTR-2H4	x2	/2.4	
Cable name =EDM+MCBN-2W5			Cable type ÖLFLEX CLASSIC 110					
Function text			No. of conductors 3G			Cross-section 1		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
				1				
				2				
				GNYE				
	/2.4	-2X4	1:3	BN	+LGTF-2H5	x1	/2.5	
	/2.5	-2X4	2:3	BU	+LGTF-2H5	x2	/2.5	

Cable name =EDM+MCBN-2W8			Cable type ÖLFLEX CLASSIC 110					
Function text			No. of conductors 3G			Cross-section 1		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
				1				
				2				
				GNYE				
	/2.8	-2F8	2	BN	-2M8	1	/2.8	
	/2.9	-2F9	2	BU	-2M8	2	/2.8	
Cable name =EDM+MCBN-3W0			Cable type SANYO.AADCABMOT-R2-3M					
Function text			No. of conductors			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
BRUSHLESS MOTOR R2AA08075F	/3.1	+BGG-3M0-M	PE	GNYE	PE		/3.2	
BRUSHLESS MOTOR R2AA08075F	/3.1	+BGG-3M0-M	U1	U	-3A1-CNC	U	/3.2	
BRUSHLESS MOTOR R2AA08075F	/3.1	+BGG-3M0-M	V1	V	-3A1-CNC	V	/3.2	
BRUSHLESS MOTOR R2AA08075F	/3.1	+BGG-3M0-M	W1	W	-3A1-CNC	W	/3.2	
Cable name =EDM+MCBN-3W2			Cable type SANYO.AADCABCOD-R2-3M					
Function text			No. of conductors			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/3.2	+BGG-3M0-ENC			-3A1-CN2		/3.2	
Cable name =EDM+MCBN-3W3			Cable type SANYO.AADCABMOT-R2-4M					
Function text			No. of conductors			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
BRUSHLESS MOTOR R2AA08075F	/3.3	+BGG-3M3-M	PE	GNYE	PE		/3.5	
BRUSHLESS MOTOR R2AA08075F	/3.3	+BGG-3M3-M	W1	U	-3A4-CNC	W	/3.5	
BRUSHLESS MOTOR R2AA08075F	/3.3	+BGG-3M3-M	V1	V	-3A4-CNC	V	/3.5	
BRUSHLESS MOTOR R2AA08075F	/3.3	+BGG-3M3-M	U1	W	-3A4-CNC	U	/3.5	

Cable name =EDM+MCBN-3W5			Cable type SANYO.AADCABCOD-R2-4M					
Function text			No. of conductors			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/3.4	+BGG-3M3-ENC			-3A4-CN2		/3.5	
Cable name =EDM+MCBN-3W6			Cable type SANYO.AADCABMOT-R2-7M					
Function text			No. of conductors			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
BRUSHLESS MOTOR R2AA08075F	/3.6	+BGG-3M6-M	PE	GNYE	PE		/3.8	
BRUSHLESS MOTOR R2AA08075F	/3.6	+BGG-3M6-M	U1	U	-3A7-CNC	U	/3.8	
BRUSHLESS MOTOR R2AA08075F	/3.6	+BGG-3M6-M	V1	V	-3A7-CNC	V	/3.8	
BRUSHLESS MOTOR R2AA08075F	/3.6	+BGG-3M6-M	W1	W	-3A7-CNC	W	/3.8	
Cable name =EDM+MCBN-3W8			Cable type SANYO.AADCABCOD-R2-7M					
Function text			No. of conductors			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/3.7	+BGG-3M6-ENC			-3A7-CN2		/3.8	
Cable name =EDM+MCBN-4W0			Cable type SANYO.AADCABMOT-R2-7M					
Function text			No. of conductors			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
BRUSHLESS MOTOR R2AA08075F	/4.0	+BGG-4M0-M	U1	U	-4A1-CNC	U	/4.2	
BRUSHLESS MOTOR R2AA08075F	/4.0	+BGG-4M0-M	V1	V	-4A1-CNC	V	/4.2	
BRUSHLESS MOTOR R2AA08075F	/4.0	+BGG-4M0-M	W1	W	-4A1-CNC	W	/4.2	
Cable name =EDM+MCBN-4W2			Cable type SANYO.AADCABCOD-R2-7M					
Function text			No. of conductors			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/4.1	+BGG-4M0-ENC			-4A1-CN2		/4.2	

Cable name =EDM+MCBN-4W3			Cable type SANYO.AADCABMOT-R2-7M					
Function text			No. of conductors			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
BRUSHLESS MOTOR R2AA08075F	/4.3	+BGG-4M3-M	U1	U	-4A4-CNC	U	/4.5	
BRUSHLESS MOTOR R2AA08075F	/4.3	+BGG-4M3-M	V1	V	-4A4-CNC	V	/4.5	
BRUSHLESS MOTOR R2AA08075F	/4.3	+BGG-4M3-M	W1	W	-4A4-CNC	W	/4.5	
Cable name =EDM+MCBN-4W5			Cable type SANYO.AADCABCOD-R2-7M					
Function text			No. of conductors			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/4.4	+BGG-4M3-ENC			-4A4-CN2		/4.5	
Cable name =EDM+MCBN-5W1			Cable type					
Function text			No. of conductors			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
				BK(L1)				
				BK(L2)				
				BK(L3)				
				GNYE				
				BK5				
				BK6				
				SH				
	/9.7		x1	BK	-9X7	2	/9.7	
	/9.7	-10X4	5	WH	-9X7	1	/9.7	
	/5.1	-5A0-M			+ACFL-5M2-M	W1	/5.2	
	/5.1	-5A0-M			+ACFL-5M2-M	V1	/5.2	
	/5.1	-5A0-M			+ACFL-5M2-M	U1	/5.2	
	/5.1				+ACFL-5M2-M	PE	/5.2	

Cable diagram

F09_002

Cable name =EDM+MCBN-5W3			Cable type KAWEFLEX 5477 SK-C-PUR UL/CSA					
Function text			No. of conductors 16		Cross-section 0,18		Cable length	
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
				SH				
				BK				
				BN				
				RD				
				OG				
				YE				
				GN				
				BU				
				VT				
				GY				
				WH				
				WHBK				
				WHBN				
				WHRD				
				WHOG				
				WHYE				
				WHGN				
	/5.2	-5A0-CN3			+ACFL-5M2-ENC	1	/5.3	

Cable name =EDM+MCBN-5W5			Cable type PUR-Servoleitung					
Function text			No. of conductors 4		Cross-section 1,5+1,5		Cable length	
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
				BK(L1)				
				BK(L2)				
				BK(L3)				
				GNYE				
				BK5				

Cable name =EDM+MCBN-5W5			Cable type PUR-Servoleitung					
Function text			No. of conductors 4			Cross-section 1,5+1,5		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
				BK6				
				SH				
	/9.8		x1	BK	-9X8	2	/9.8	
	/9.8	-10X4	6	WH	-9X8	1	/9.8	
	/5.5	-5A4-M			+ACFR-5M6-M	W1	/5.6	
	/5.5	-5A4-M			+ACFR-5M6-M	V1	/5.6	
	/5.5	-5A4-M			+ACFR-5M6-M	U1	/5.6	
	/5.5				+ACFR-5M6-M	PE	/5.6	
Cable name =EDM+MCBN-5W7			Cable type KAWEFLEX 5477 SK-C-PUR UL/CSA					
Function text			No. of conductors 16			Cross-section 0,18		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
				SH				
				BK				
				BN				
				RD				
				OG				
				YE				
				GN				
				BU				
				VT				
				GY				
				WH				
				WHBK				
				WHBN				
				WHRD				
				WHOG				

Cable name =EDM+MCBN-5W7			Cable type KAWEFLEX 5477 SK-C-PUR UL/CSA					
Function text			No. of conductors 16			Cross-section 0,18		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
				WHYE				
				WHGN				
	/5.6	-5A4-CN3			+ACFR-5M6-ENC	1	/5.7	

Cable name =EDM+MCBN-7W1			Cable type LIYCY FLEX					
Function text			No. of conductors 12			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/7b.4	-7X1	3:3	1	+MSB1-1X6	1	/7b.4	
	/7b.3	-7X1	2:3	2	+MSB1-1X6	2	/7b.3	
	/7b.3	-7X1	1:3	3	+MSB1-1X6	3	/7b.3	
	/7b.1	-7X1	1:1	4	+MSB1-1X6	4	/7b.1	
	/7b.1	-7X1	2:1	5	+MSB1-1X6	5	/7b.1	
	/7b.2	-7X1	3:1	5	+MSB1-1X6	5	/7b.1	
	/7.1	-7X1	3:1	BN	+MSB1-CRWN	11	/7.1	
	/7a.1	-7X1	1:1	BN	+MSB1-CRWN	15	/7a.2	
	/7.3	-7X1	2:3	BU	+MSB1-CRWN	19	/7.3	
	/7a.3	-7X1	2:3	BU	+MSB1-CRWN	19	/7a.3	
	/7.2	-7X1	1:1	GN	+MSB1-CRWN	15	/7.2	
	/7a.2	-7X1	3:1	GN	+MSB1-CRWN	11	/7a.1	
	/7.3	-7X1	1:3	PK	+MSB1-CRWN	18	/7.3	
	/7a.3	-7X1	1:3	PK	+MSB1-CRWN	18	/7a.3	
	/7.4	-7X1	3:3	RD	+MSB1-CRWN	20	/7.4	
	/7a.4	-7X1	3:3	RD	+MSB1-CRWN	20	/7a.4	
	/7.1	-7X1	2:1	WH	+MSB1-CRWN	12	/7.1	
	/7a.1	-7X1	2:1	WH	+MSB1-CRWN	12	/7a.1	

Cable name =EDM+MCBN-9W2			Cable type LIYCY FLEX					
Function text			No. of conductors 4			Cross-section 0,34		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/9.2	+BGG-YP1_2-YP1_2		BN	-19K5	14	/9.2	
	/9.2	+BGG-YP1_2-YP1_2		WH	-9X1	10	/9.2	
Cable name =EDM+MCBN-9W3			Cable type LIYCY FLEX					
Function text			No. of conductors 4			Cross-section 0,34		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/9.2	+BGG-YP1_2-YP1_2		BN	-19K6	14	/9.3	
	/9.2	+BGG-YP1_2-YP1_2		WH	-9X1	9	/9.3	
Cable name =EDM+MCBN-9W5			Cable type LIYCY FLEX					
Function text			No. of conductors 20			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/14.1	-9X6.A	14	BK	-7X0	1:4	/14.1	
	/38.4	-9X6.A	8	BN	-33X9	12:2	/38.4	
	/14.5	-9X6.A	17	BN/GY	-7X0	5:4	/14.6	
	/31.9	-9X6.A	16	BN/PK	-9X5	8:1	/31.9	
	/31a.9	-9X6.A	16	BN/PK	-9X5	8:1	/31a.9	
	/9.5	-9X6.B	16	BN/YE	+NMC1-9H5	BN/YE	/9.5	CNC READY
	/9.6	-9X6.A	2	BU	+NMC1-9R5	BU	/9.5	
	/14.1	-9X6.A	7	GN	-7X0	2:4	/14.1	
	/14.5	-9X6.A	10	GN/WH	-7X0	10:4	/14.6	
	/14.5	-9X6.A	5	GY	-7X0	7:4	/14.6	
	/30.2	-9X6.A	3	PK	-9X5	7:1	/30.2	
	/14.1	-9X6.A	1	RD	-7X0	11:4	/14.1	
	/30.1	-9X6.A	11	RD/BU	-39X2	1:3	/30.1	
	/37.9	-9X6.A	13	VT	-9X5	14:1	/37.9	
	/30.1	-9X6.A	4	WH/PK	-9X5	6:1	/30.1	
	/37.7	-9X6.A	6	YE	-9X5	12:1	/37.7	

Cable name =EDM+MCBN-9W5			Cable type LIYCY FLEX					
Function text			No. of conductors 20			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/37.8	-9X6.B	17	YE/WH	-9X5	13:1	/37.8	
Cable name =EDM+MCBN-10W0			Cable type MULTISPEED®-TRONIC-PUR					
Function text			No. of conductors 4,0			Cross-section 0,34		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/10.0	-46X2	5:2	WH	+ACF-10B0	3	/10.0	
	/10.0	-46X2	1:4	BN	+ACF-10B0	1	/10.0	
				GN				
				YE				
	/10.1	-46X2	4:4	BU	+ACF-10B0	2	/10.0	
Cable name =EDM+MCBN-10W1			Cable type MULTISPEED®-TRONIC-PUR					
Function text			No. of conductors 4,0			Cross-section 0,34		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/10.1	-46X2	6:2	WH	+ACF-10B1	3	/10.1	
	/10.1	-46X2	2:4	BN	+ACF-10B1	1	/10.1	
				GN				
				YE				
	/10.2	-46X2	5:4	BU	+ACF-10B1	2	/10.1	
Cable name =EDM+MCBN-10W4			Cable type LIYCY					
Function text			No. of conductors 4			Cross-section 0,34		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/10.4	-10X4	1:3	BN	+HBC-10S4	1	/10.4	
	/10.4	-10X4	1:1	YE	+HBC-10S4	3	/10.4	
	/10.5	-10X4	2:1		+HBC-10S4	2	/10.4	

Cable diagram

F09_002

Cable name =EDM+MCBN-10W5			Cable type ÖLFLEX CLASSIC 110					
Function text			No. of conductors 3G			Cross-section 1		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
				1				
				2				
				GNYE				
	/10.5	-10X4	3:1	BN	+HBC-Y30	x1	/10.5	
	/10.5	-10X4	3:3	BU	+HBC-Y30	x2	/10.5	
	/10.5		x1	BU	+HBC-Y30	x2	/10.5	
Cable name =EDM+MCBN-10W6			Cable type ÖLFLEX CLASSIC 110					
Function text			No. of conductors 3G			Cross-section 1		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
				1				
				2				
				GNYE				
	/10.6	-10X4	4:1	BN	+HBC-Y31	x1	/10.6	
	/10.6	-10X4	4:3	BU	+HBC-Y31	x2	/10.6	
	/10.6		x1	BU	+HBC-Y31	x2	/10.6	
Cable name =EDM+MCBN-11W0			Cable type DK-HSB-RJ45-05					
Function text			No. of conductors			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/11.0	+NMC1-11A0-ETH	1		-11X0	1	/11.0	
	/11.0	+NMC1-11A0-ETH	2		-11X0	2	/11.0	
	/11.0	+NMC1-11A0-ETH	3		-11X0	3	/11.0	
	/11.0	+NMC1-11A0-ETH	4		-11X0	4	/11.0	
	/11.0	+NMC1-11A0-ETH	5		-11X0	5	/11.0	
	/11.1	+NMC1-11A0-ETH	6		-11X0	6	/11.0	
	/11.1	+NMC1-11A0-ETH	6		-11X0	7	/11.0	
	/11.1	+NMC1-11A0-ETH	7		-11X0	8	/11.0	

Cable name =EDM+MCBN-11W4			Cable type DK-HSB-RJ45-05					
Function text			No. of conductors			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/11.4	-11A3	HSB_L		-11A5	HSB_L	/11.6	
Cable name =EDM+MCBN-11W5			Cable type DK-1080-002					
Function text			No. of conductors			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/11.5	-11X2	2:4	1	-11A5	24V	/11.6	
	/11.5	-11X2	2:2	2	-11A5	0V	/11.6	
Cable name =EDM+MCBN-11W6			Cable type DK-HSB-RJ45-05					
Function text			No. of conductors			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/11.6	-11A5	HSB_H		-11A8	HSB_H	/11.8	
	/11.6	-11A5	GND		-11A8	GND	/11.8	
	/11.6	-11A5	HSB_L		-11A8	HSB_L	/11.8	
Cable name =EDM+MCBN-11W8			Cable type DK-1080-002					
Function text			No. of conductors			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/11.7	-11X2	3:4	1	-11A8	24V	/11.8	
	/11.7	-11X2	3:2	2	-11A8	0V	/11.8	
Cable name =EDM+MCBN-12W1			Cable type DK-1080-002					
Function text			No. of conductors			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/12.1	-11X2	5:4	1	-12A1	24V	/12.1	
	/12.1	-11X2	5:2	2	-12A1	0V	/12.1	

Cable name =EDM+MCBN-13W4			Cable type LIYCY					
Function text			No. of conductors 12			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/11	-13A3-COM2	1		-COM2	1	/11	
	/11	-13A3-COM2	6		-COM2	6	/11	
	/11	-13A3-COM2	9		-COM2	9	/11	
	/11.0	-13A3-COM2	1		+NMC1-11A0-COM1	1	/11.0	
	/11.1	-13A3-COM2	6		+NMC1-11A0-COM1	6	/11.1	
	/11.1	-13A3-COM2	2		+NMC1-11A0-COM1	2	/11.1	
	/11.1	-13A3-COM2	7		+NMC1-11A0-COM1	7	/11.1	
	/11.1	-13A3-COM2	3		+NMC1-11A0-COM1	3	/11.1	
	/11.1	-13A3-COM2	8		+NMC1-11A0-COM1	8	/11.1	
	/11.1	-13A3-COM2	4		+NMC1-11A0-COM1	4	/11.1	
	/11.1	-13A3-COM2	9		+NMC1-11A0-COM1	9	/11.1	
	/11.1	-13A3-COM2	5		+NMC1-11A0-COM1	5	/11.1	
	/13.4	-13A3-COM2	1		+NMC1-11A0-COM1	1	/13.5	
	/13.4	-13A3-COM2	6		+NMC1-11A0-COM1	6	/13.5	
	/13.4	-13A3-COM2	2		+NMC1-11A0-COM1	2	/13.5	
	/13.4	-13A3-COM2	7		+NMC1-11A0-COM1	7	/13.5	
	/13.4	-13A3-COM2	3		+NMC1-11A0-COM1	3	/13.5	
	/13.4	-13A3-COM2	8		+NMC1-11A0-COM1	8	/13.5	
	/13.4	-13A3-COM2	4		+NMC1-11A0-COM1	4	/13.5	
	/13.4	-13A3-COM2	9		+NMC1-11A0-COM1	9	/13.5	
	/13.4	-13A3-COM2	5		+NMC1-11A0-COM1	5	/13.5	
Cable name =EDM+MCBN-15W1			Cable type DK-1079-002					
Function text			No. of conductors 16			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/15.1	-15X0	10:2		-11A3-XV	1	/15.1	
	/15.2	-15X0	2:4		-11A3-XV	2	/15.2	

Cable name =EDM+MCBN-15W1			Cable type DK-1079-002					
Function text			No. of conductors 16			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/15.2	-15X0	3:4		-11A3-XV	10	/15.2	
	/15.3	-15X0	4:4		-11A3-XV	3	/15.3	
	/15.3	-15X0	5:4		-11A3-XV	11	/15.3	
	/15.4	-15X0	3:2		-11A3-XV	9	/15.4	
	/15.4	-15X0	4:2		-11A3-XV	15	/15.4	
	/15.4	-15X0	7:4		-11A3-XV	16	/15.4	
	/15.5	-15X0	6:4		-11A3-XV	8	/15.5	
	/15.5	-15X0	9:2		-11A3-XV	7	/15.5	
	/15.6	-15X0	5:2		-11A3-XV	12	/15.6	
	/15.6	-15X0	8:4		-11A3-XV	5	/15.6	
	/15.7	-15X0	9:4		-11A3-XV	13	/15.7	
	/15.7	-15X0	10:4		-11A3-XV	6	/15.7	
	/15.7	-15X0	11:4		-11A3-XV	14	/15.7	
	/15.8	-15X0	8:2		-11A3-XV	4	/15.8	
Cable name =EDM+MCBN-15W2			Cable type UNITRONIC® LIYCY					
Function text			No. of conductors 4			Cross-section 0,5		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/15.2	-15X0	3:3	WH	+HBL-Y1-Y24	1	/15.2	
	/15.2	-15X0	2:3	BN	+HBL-Y1-Y24	2	/15.2	
				GN				
				YE				
				SH				
	/15.2	-15X0	1	GN	-15X0	1:2	/15.1	
	/15.3	-15X0	1	GN	-15X0	1	/15.2	

Cable name =EDM+MCBN-15W7			Cable type UNITRONIC® LIYCY					
Function text			No. of conductors 4			Cross-section 0,5		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/15.7	-15X0	11:3	WH	+HBR-Y2-Y27	1	/15.7	
	/15.7	-15X0	10:3	BN	+HBR-Y2-Y27	2	/15.8	
				GN				
				YE				
				SH				
Cable name =EDM+MCBN-16W2			Cable type LIYCY FLEX					
Function text			No. of conductors 12			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/16.6	-16X2	5:3	BK	-11A3-X1		/16.6	
	/16.2	-16X2	7:1	BU	-11A3-X1		/16.2	
	/16.6	-16X2	6:3	GN	-11A3-X1		/16.6	
	/16.4	-16X2	2:1	GY	-11A3-X1		/16.4	
	/16.3	-16X2	1:1	PK	-11A3-X1		/16.3	
	/16.8	-16X2	6:1	RD	-11A3-X1		/16.8	
	/16.5	-16X2	4:3	VT	-11A3-X1		/16.5	
	/16.5	-16X2	3:1	WH	-11A3-X1		/16.5	
	/16.7	-16X2	7:3	YE	-11A3-X1		/16.7	
Cable name =EDM+MCBN-17W2			Cable type LIYCY FLEX					
Function text			No. of conductors 12			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/17.2	-17X2	5:1		-11A3-X2		/17.2	
	/17.3	-17X2	1:3		-11A3-X2		/17.3	
	/17.4	-17X2	1:1		-11A3-X2		/17.4	
	/17.5	-17X2	2:3		-11A3-X2		/17.5	
	/17.5	-17X2	3:3		-11A3-X2		/17.5	
	/17.6	-17X2	4:3		-11A3-X2		/17.6	

Cable name =EDM+MCBN-17W2			Cable type LIYCY FLEX					
Function text			No. of conductors 12			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/17.6	-17X2	5:3		-11A3-X2		/17.6	
	/17.8	-17X2	4:1		-11A3-X2		/17.8	
Cable name =EDM+MCBN-18W2			Cable type LIYCY FLEX					
Function text			No. of conductors 12			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/18.3	-18X2	4:3	BN	-11A3-X3		/18.3	
	/18.2	-18X2	6:1		-11A3-X3		/18.2	
	/18.3	-18X2	1:1		-11A3-X3		/18.3	
	/18.4	-18X2	2:1		-11A3-X3		/18.4	
	/18.5	-18X2	5:3		-11A3-X3		/18.5	
	/18.6	-18X2	6:3		-11A3-X3		/18.6	
	/18.6	-18X2	3:3		-11A3-X3		/18.6	
	/18.8	-18X2	5:1		-11A3-X3		/18.8	
Cable name =EDM+MCBN-19W2			Cable type LIYCY FLEX					
Function text			No. of conductors 12			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/19.6	-19X2	2:3	BK	-11A5-X1		/19.6	
	/19.2	-19X2	5:1	BU	-11A5-X1		/19.2	
	/19.6	-19X2	1:1	GN	-11A5-X1		/19.6	
	/19.4	-19X2	2:1	GY	-11A5-X1		/19.4	
	/19.3	-19X2	5:3	PK	-11A5-X1		/19.3	
	/19.8	-19X2	4:1	RD	-11A5-X1		/19.8	
	/19.5	-19X2	1:3	VT	-11A5-X1		/19.5	
	/19.5	-19X2	3:1	WH	-11A5-X1		/19.5	
	/19.7	-19X2	4:3	YE	-11A5-X1		/19.7	

Cable diagram

F09_002

Cable name =EDM+MCBN-19W3			Cable type ELITRONIC-CY LIYCY					
Function text			No. of conductors 3			Cross-section 0,14		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
				SH				
	/19.3	-19X2	3:4	WH	-19S3		/19.3	
				BN				
				GN				
	/19.3	-19X2	4:2	BN	-19S3		/19.3	
Cable name =EDM+MCBN-19W4			Cable type ELITRONIC-CY LIYCY					
Function text			No. of conductors 3			Cross-section 0,14		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
				SH				
	/19.3	-19X2	5:4	WH	-19S4		/19.4	
				BN				
				GN				
	/19.4	-19X2	3:2	BN	-19S4		/19.4	
Cable name =EDM+MCBN-20W2			Cable type LIYCY FLEX					
Function text			No. of conductors 12			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/20.2	-20X2	3:1		-11A5-X3		/20.2	
	/20.4	-20X2	1:1		-11A5-X3		/20.4	
	/20.5	-20X2	1:3		-11A5-X3		/20.5	
	/20.7	-20X2	2:3		-11A5-X3		/20.7	
	/20.8	-20X2	2:1		-11A5-X3		/20.8	
Cable name =EDM+MCBN-21W2			Cable type LIYCY FLEX					
Function text			No. of conductors 12			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/21.6	-21X2	4:3	BK	-11A8-X1		/21.6	

20

22

Cable name =EDM+MCBN-21W2			Cable type LIYCY FLEX					
Function text			No. of conductors 12			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/21.2	-21X2	5:1	BU	-11A8-X1		/21.2	
	/21.4	-21X2	2:3	GY	-11A8-X1		/21.4	
	/21.3	-21X2	5:3	PK	-11A8-X1		/21.3	
	/21.8	-21X2	4:1	RD	-11A8-X1		/21.8	
	/21.5	-21X2	3:3	WH	-11A8-X1		/21.5	
	/21.7	-21X2	1	YE	-11A8-X1		/21.7	
Cable name =EDM+MCBN-22W2			Cable type LIYCY FLEX					
Function text			No. of conductors 12			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/22.2	-22X2	5:1	BU	-11A8-X3		/22.2	
	/22.4	-22X2	2:3	GY	-11A8-X3		/22.4	
	/22.8	-22X2	4:1	RD	-11A8-X3		/22.8	
	/22.5	-22X2	3:3	WH	-11A8-X3		/22.5	
	/22.7	-22X2	1:3	YE	-11A8-X3		/22.7	
Cable name =EDM+MCBN-23W2			Cable type LIYCY FLEX					
Function text			No. of conductors 12			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/23.2	-23X2	5:1	BU	-12A1-X1		/23.2	
	/23.6	-23X2	1:3	GN	-12A1-X1		/23.6	
	/23.4	-23X2	3:3	GY	-12A1-X1		/23.4	
	/23.8	-23X2	4:1	RD	-12A1-X1		/23.8	
	/23.5	-23X2	4:3	WH	-12A1-X1		/23.5	
	/23.7	-23X2	2:3	YE	-12A1-X1		/23.7	

Cable name =EDM+MCBN-24W2			Cable type LIYCY FLEX					
Function text			No. of conductors 12			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/24.2	-24X2	5:1	BU	-12A1-X3		/24.2	
	/24.6	-24X2	1:3	GN	-12A1-X3		/24.6	
	/24.4	-24X2	4:3	GY	-12A1-X3		/24.4	
	/24.8	-24X2	4:1	RD	-12A1-X3		/24.8	
	/24.5	-24X2	3:3	WH	-12A1-X3		/24.5	
	/24.7	-24X2	2:3	YE	-12A1-X3		/24.7	
Cable name =EDM+MCBN-25W1			Cable type UNITRONIC® LIYCY					
Function text			No. of conductors 4			Cross-section 0,34		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/25.2	-11A3-XB		WH	+HBL-Y1-LVDTY1	2	/15.2	
	/32.4	-13A3-E05	+	BN	+HBL-Y1-LVDTY1	4	/15.2	
	/25.2	-11A3-XB		GN	+HBL-Y1-LVDTY1	1	/15.1	
	/25.3	-11A3-XB		YE	+HBL-Y1-LVDTY1	3	/15.2	
				SH				
Cable name =EDM+MCBN-25W6			Cable type UNITRONIC® LIYCY					
Function text			No. of conductors 4			Cross-section 0,34		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/25.7	-11A3-XB		WH	+HBR-Y2-LVDTY2	2	/15.8	
	/32.5	-13A3-E05	+	BN	+HBR-Y2-LVDTY2	4	/15.8	
	/25.6	-11A3-XB		GN	+HBR-Y2-LVDTY2	1	/15.8	
	/25.8	-11A3-XB		YE	+HBR-Y2-LVDTY2	3	/15.8	
				SH				

Cable name =EDM+MCBN-27W5			Cable type UNITRONIC® LIYCY					
Function text			No. of conductors 4			Cross-section 0,5		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
				WH				
	/27.5	-43X0	5:4	BN	-11A5-XA		/27.5	
				GN				
				YE				
				SH				
	/27.5	-43X0	5	BN	-43X0	5:4	/43.4	
	/27.6	-43X0	6:4		-11A5-XA		/27.6	
	/27.6	-43X0	6		-43X0	6:4	/43.5	
Cable name =EDM+MCBN-28W0			Cable type UNITRONIC® LIYCY					
Function text			No. of conductors 4			Cross-section 0,5		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/28.6	-45X1	6:4	WH	-11A8-XA		/28.6	
	/28.0	-44X0	5:4	BN	-11A8-XA		/28.0	
	/28.5	-45X1	5:4	GN	-11A8-XA		/28.5	
	/28.1	-44X0	6:4	YE	-11A8-XA		/28.1	
				SH				
	/28.0	-44X0	5	BN	-44X0	5:4	/44.4	
	/28.5	-45X1	5	GN	-45X1	5:4	/45.4	
	/28.6	-45X1	6	WH	-45X1	6:4	/45.5	
	/28.1	-44X0	6	YE	-44X0	6:4	/44.5	
Cable name =EDM+MCBN-29W0			Cable type LIYCY					
Function text			No. of conductors 4			Cross-section 0,34		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/29.0	-12A1-XA		BN	-5A0-CN1		/46.4	
	/29.1	-12A1-XA		YE	-5A0-CN1		/46.4	

Cable name =EDM+MCBN-29W5			Cable type LIYCY					
Function text			No. of conductors 4			Cross-section 0,34		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/29.5	-12A1-XA		BN	-5A4-CN1		/48.4	
	/29.6	-12A1-XA		YE	-5A4-CN1		/48.4	
Cable name =EDM+MCBN-30W7			Cable type LIYCY FLEX					
Function text			No. of conductors 4			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/30.8	-6X1	9:3	BN	+DS1-30S7	BN	/30.8	
	/30.9	-6X1	10:3	BN	+DS2-30S8	BN	/30.9	
	/30.8	-9X1	2:3	GN	+DS2-30S8	GN	/30.8	
	/30.9	-9X1	1:3	GN		GN	/30.9	
	/30.8	-13A3-E03	+	WH	+DS1-30S7	WH	/30.8	
	/30.9	-13A3-E03	+	WH	+DS2-30S8	WH	/30.9	
-	/30.8	-13A3-E03	-	YE	+DS2-30S8	YE	/30.8	
-	/30.9	-13A3-E03	-	YE		YE	/30.9	
Cable name =EDM+MCBN-32W0			Cable type UNITRONIC® LIYCY					
Function text			No. of conductors 4			Cross-section 0,5		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/32.1	-32X1	1:1	WH	+HBL-32B0	4	/32.1	
	/32.1	-32X1	5:1	BN	+HBL-32B0	1	/32.1	
				GN				
				YE				
				SH				
	/32.1	-32X1	4:1	GN	+HBL-32B0-PE	3	/32.1	
	/32.1	-32H1	x1	WH	+HBL-32B0	4	/32.1	

Cable diagram

F09_002

Cable name =EDM+MCBN-32W2			Cable type UNITRONIC® LIYCY					
Function text			No. of conductors 4			Cross-section 0,5		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/32.2	-32X1	2:1	WH	+HBR-32B1	4	/32.2	
	/32.2	-32X1	5:3	BN	+HBR-32B1	1	/32.2	
				GN				
				YE				
				SH				
	/32.2	-32X1	4:1	GN	+HBR-32B1-PE	3	/32.2	
	/32.2	-32H2	x1	WH	+HBR-32B1	4	/32.2	
Cable name =EDM+MCBN-32W3			Cable type UNITRONIC® LIYCY					
Function text			No. of conductors 4			Cross-section 0,5		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/32.3	-32X1	3:1	WH	+HBC-32B3	4	/32.3	
	/32.3	-32X1	6:1	BN	+HBC-32B3	1	/32.3	
				GN				
				YE				
				SH				
	/32.4	-32X1	4:1	GN	+HBC-32B3-PE	3	/32.3	
	/32.4	-32H4	x1	WH	+HBC-32B3	4	/32.3	
Cable name =EDM+MCBN-35W0			Cable type H05W-F					
Function text			No. of conductors 3G			Cross-section 1		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/35.1	-32X1	8:1	BN	+HBL-Y21	x1	/35.1	
	/35.1	-32X1	8:1	BN		x2	/35.1	
	/35.1	-32X1	8:3	BU	+HBL-Y21	x2	/35.1	
	/35.1	-32X1	7:1	GNYE	+HBL-Y21	PE	/35.1	

Cable name =EDM+MCBN-35W2			Cable type H05W-F					
Function text			No. of conductors 3G			Cross-section 1		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/35.2	-32X1	9:1	BN	+HBC-Y23	x1	/35.2	
	/35.2	-32X1	9:1	BN		x2	/35.3	
	/35.2	-32X1	9:3	BU	+HBC-Y23	x2	/35.2	
	/35.2	-32X1	7:1	GNYE	+HBC-Y23	PE	/35.2	
Cable name =EDM+MCBN-35W3			Cable type H05W-F					
Function text			No. of conductors 3G			Cross-section 1		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/35.3	-32X1	10:1	BN	+HBR-Y22	x1	/35.3	
	/35.3	-32X1	10:1	BN		x2	/35.4	
	/35.3	-32X1	10:3	BU	+HBR-Y22	x2	/35.3	
	/35.4	-32X1	7:1	GNYE	+HBR-Y22	PE	/35.3	
Cable name =EDM+MCBN-38W1			Cable type UNITRONIC® LIYCY					
Function text			No. of conductors 12			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/38.4	-33X9	11:3	WH	+SCCT-38A1-2		/38.1	
	/38.4	-33X9	12:1	BN	+SCCT-38A1	1	/38.1	
				GN				
				SH				
	/38a.4	-33X9	2:3	WH	+SCCT-38A1	2	/38a.2	
	/38a.3	-33X9	1:3	BN	+SCCT-38A1	1	/38a.2	
				GN				
				YE				
				GY				
				PK				
	/38a.4	-33X9	12:3	BU	+SCCT-38A1	4	/38a.2	
				RD				

Cable name =EDM+MCBN-38W1			Cable type UNITRONIC® LIYCY					
Function text			No. of conductors 12			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
				BK				
				VT				
				GYPK				
				RDBU				
				SH				
	/38b.4	-33X9	2:3	WH	+SCCT-38A1	2	/38b.2	
	/38b.3	-33X9	1:3	BN	+SCCT-38A1	1	/38b.2	
				GN				
				YE				
				GY				
				PK				
	/38b.4	-33X9	12:3	BU	+SCCT-38A1	4	/38b.2	
				RD				
				BK				
				VT				
				GYPK				
				RDBU				
				SH				
	/38.2	-33X9	13:1	GN	+SCCT-38A1-6		/38.2	
	/38a.2	-33X9	13:1	GN	+SCCT-38A1	5	/38a.2	
	/38b.2	-33X9	13:1	GN	+SCCT-38A1	5	/38b.2	
Cable name =EDM+MCBN-38W3			Cable type OLFLEX 110					
Function text			No. of conductors 21G			Cross-section 0,5		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/38a.3	-33X9	1:4	1	+SCCR-38A3	1H	/38a.3	
	/38b.3	-33X9	1:4	1	+SCCR-38A3	1H	/38b.3	

Cable name =EDM+MCBN-38W3			Cable type OLFLEX 110					
Function text			No. of conductors		21G	Cross-section 0,5		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/38.4	-33X9	4:2	2	+SCCR-38A3	2	/38.4	
	/38a.4	-33X9	2:4	2	+SCCR-38A3	2H	/38a.4	
	/38b.4	-33X9	2:4	2	+SCCR-38A3	2H	/38b.4	
	/38a.4	-33X9	3:4	3	+SCCR-38A3	3H	/38a.4	
	/38b.4	-33X9	3:4	3	+SCCR-38A3	3H	/38b.4	
	/38a.6	-33X9	8:2	4	+SCCR-38A3	4H	/38a.6	
	/38b.6	-33X9	8:2	4	+SCCR-38A3	4H	/38b.6	
	/38a.7	-33X9	9:2	5	+SCCR-38A3	5H	/38a.7	
	/38b.7	-33X9	9:2	5	+SCCR-38A3	5H	/38b.7	
	/38.4	-33X9	12:4	6	+SCCR-38A3	6	/38.4	
	/38a.5	-33X9	11:2	6	+SCCR-38A3	6H	/38a.5	
	/38b.5	-33X9	11:2	6	+SCCR-38A3	6H	/38b.5	
	/38.6	-33X9	9:2	7	+SCCR-38A3	7	/38.6	
	/38a.4	-33X9	2:2	7	+SCCR-38A3	7H	/38a.4	
	/38b.4	-33X9	2:2	7	+SCCR-38A3	7H	/38b.4	
	/38.7	-33X9	8:4	8	+SCCR-38A3	8	/38.7	
	/38a.5	-33X9	3:2	8	+SCCR-38A3	8H	/38a.5	
	/38b.5	-33X9	3:2	8	+SCCR-38A3	8H	/38b.5	
	/38.5	-33X9	5:2	9	+SCCR-38A3	9	/38.5	
	/38a.4	-33X9	4:2	9	+SCCR-38A3	9H	/38a.4	
	/38b.4	-33X9	4:2	9	+SCCR-38A3	9H	/38b.4	
	/38.6	-33X9	7:2	10	+SCCR-38A3	10	/38.6	
	/38a.6	-39X2	7:1	10	+SCCR-38A3	10H	/38a.6	
	/38b.6	-39X2	7:1	10	+SCCR-38A3	10H	/38b.6	
	/38.6	-33X9	6:2	11	+SCCR-38A3	11	/38.6	
	/38a.4	-33X9	12:2	11	+SCCR-38A3	11H	/38a.4	
	/38b.4	-33X9	12:2	11	+SCCR-38A3	11H	/38b.4	

Cable name =EDM+MCBN-38W3			Cable type OLFLEX 110					
Function text			No. of conductors 21G			Cross-section 0,5		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/38.5	-33X9	10:2	15	+SCCR-38A3	15	/38.5	
	/38a.5	-33X9	10:2	16	+SCCR-38A3	5V	/38a.5	
	/38b.5	-33X9	10:2	16	+SCCR-38A3	5V	/38b.5	
	/38a.5	-33X9	1:2	17	+SCCR-38A3	4V	/38a.5	
	/38b.5	-33X9	1:2	17	+SCCR-38A3	4V	/38b.5	
	/38a.6	-33X9	7:2	18	+SCCR-38A3	3V	/38a.6	
	/38b.6	-33X9	7:2	18	+SCCR-38A3	3V	/38b.6	
	/38a.5	-33X9	5:2	19	+SCCR-38A3	2V	/38a.5	
	/38b.5	-33X9	5:2	19	+SCCR-38A3	2V	/38b.5	
	/38a.5	-33X9	6:2	20	+SCCR-38A3	1V	/38a.5	
	/38b.5	-33X9	6:2	20	+SCCR-38A3	1V	/38b.5	
	/38a.7	-33X9	13:2	GNYE	+SCCR-38A3	14H	/38a.7	
	/38b.7	-33X9	13:2	GNYE	+SCCR-38A3	14H	/38b.7	
	/38.4	-33X9	11:4		+SCCR-38A3-5		/38.4	
	/38.4	-33X9	2:2		+SCCR-38A3-13		/38.4	
	/38.5	-33X9	3:2		+SCCR-38A3-14		/38.5	
	/38.5	-33X9	1:2		+SCCR-38A3-12		/38.5	
	/38.6	-33X9	11:2		+SCCR-38A3-20		/38.6	
	/38.6	-39X2	7:1		+SCCR-38A3-3		/38.6	
	/38.7	-33X9	13:2		+SCCR-38A3-1		/38.7	
Cable name =EDM+MCBN-39W2			Cable type OP-COAXIAL					
Function text			No. of conductors 4			Cross-section		Cable length 10
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/39.2	-39X2	2:1	BN	+LBT-39A3	1	/39.3	
	/39.6	+LBR-39A5	3	BN	+LBT-39A3	1	/39.3	
	/39.2	-39X2	8:1	BU	+LBT-39A3	3	/39.3	

Cable name =EDM+MCBN-41W3.1			Cable type					
Function text			No. of conductors			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/41.3	-41X0	4:4	BN	-41S3.1	12	/41.3	
	/41.3	-41X0	6:2	BU	-41S3.1	11	/41.3	
Cable name =EDM+MCBN-41W6			Cable type LIYCY					
Function text			No. of conductors 12			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/41.8	-11A3-XE3		BK	-3A1-CN1		/41.8	
	/41.8	-11A3-XE3		BN	-3A1-CN1		/41.8	
	/41.7	-11A3-XE3		GN	-3A1-CN1		/41.7	
	/41.6	-11A3-XE3		GY	-3A1-CN1		/41.6	
	/41.9	-11A3-XE3		PK	-3A1-CN1		/41.9	
	/41.7	-11A3-XE3		RD	-3A1-CN1		/41.7	
	/41.6	-11A3-XE3		YE	-3A1-CN1		/41.6	
Cable name =EDM+MCBN-42W1			Cable type LIYCY					
Function text			No. of conductors 12			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/42.3	-42X1	3:1	BK	-3A4-CN1		/42.3	
	/42.4	-42X1	5:3	BN	-3A4-CN1		/42.4	
	/42.1	-42X1	7:1	BU	-3A4-CN1		/42.1	
	/42.1	-3A4-CN1		BU	-3A4-CN1		/42.4	
	/42.2	-42X1	2:1	GN	-3A4-CN1		/42.2	
	/42.2	-42X1	1:1	PK	-3A4-CN1		/42.2	
	/42.1	-42X1	5:1	RD	-3A4-CN1		/42.1	
	/42.5	-42X1	7:3	RDBU	-3A4-CN1		/42.5	
	/42.3	-42X1	4:1	VT	-3A4-CN1		/42.3	
	/42.5	-42X1	6:3	YE	-3A4-CN1		/42.5	

Cable name =EDM+MCBN-42W3			Cable type					
Function text			No. of conductors			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/42.3	-42X1	4:2	BN	-42S3	12	/42.3	
	/42.3	-42X1	6:2	BU	-42S3	11	/42.3	
Cable name =EDM+MCBN-42W3.1			Cable type					
Function text			No. of conductors			Cross-section		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/42.3	-42X1	3:4	BN	-42S3.1	12	/42.3	
	/42.3	-42X1	5:2	BU	-42S3.1	11	/42.3	
Cable name =EDM+MCBN-42W6			Cable type LIYCY					
Function text			No. of conductors 12			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/42.8	-11A5-XE1		BK	-3A4-CN1		/42.8	
	/42.8	-11A5-XE1		BN	-3A4-CN1		/42.8	
	/42.7	-11A5-XE1		GN	-3A4-CN1		/42.7	
	/42.6	-11A5-XE1		GY	-3A4-CN1		/42.6	
	/42.9	-11A5-XE1		PK	-3A4-CN1		/42.9	
	/42.7	-11A5-XE1		RD	-3A4-CN1		/42.7	
	/42.6	-11A5-XE1		YE	-3A4-CN1		/42.6	
Cable name =EDM+MCBN-43W0			Cable type LIYCY					
Function text			No. of conductors 12			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/43.3	-43X0	4:1	BK	-3A7-CN1		/43.3	
	/43.4	-43X0	5:3	BN	-3A7-CN1		/43.4	
	/43.1	-43X0	7:1	BU	-3A7-CN1		/43.1	
	/43.1	-3A7-CN1		BU	-3A7-CN1		/43.4	
	/43.2	-43X0	2:1	GN	-3A7-CN1		/43.2	

Cable name =EDM+MCBN-43W0			Cable type LIYCY					
Function text			No. of conductors 12			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/43.2	-43X0	1:1	PK	-3A7-CN1		/43.2	
	/43.1	-43X0	5:1	RD	-3A7-CN1		/43.1	
	/43.3	-43X0	3:1	VT	-3A7-CN1		/43.3	
	/43.5	-43X0	6:3		-3A7-CN1		/43.5	
Cable name =EDM+MCBN-43W3			Cable type UNITRONIC® LIYCY					
Function text			No. of conductors 4			Cross-section 0,5		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/43.3	-43X0	6:2	WH	-43S3.1	11	/43.3	
	/43.3	-43X0	3:4	BN	-43S3.1	12	/43.3	
	/43.3	-43X0	4:2	GN	-43S3	12	/43.3	
	/43.3	-43X0	5:2	YE	-43S3	11	/43.3	
				SH				
Cable name =EDM+MCBN-43W6			Cable type LIYCY					
Function text			No. of conductors 12			Cross-section 0,25		Cable length
Function text	Page / column	Target designation from	Connection point	Conductor	Target designation to	Connection point	Page / column	Function text
	/43.8	-11A5-XE2		BK	-3A7-CN1		/43.8	
	/43.8	-11A5-XE2		BN	-3A7-CN1		/43.8	
	/43.7	-11A5-XE2		GN	-3A7-CN1		/43.7	
	/43.6	-11A5-XE2		GY	-3A7-CN1		/43.6	
	/43.9	-11A5-XE2		PK	-3A7-CN1		/43.9	
	/43.7	-11A5-XE2		RD	-3A7-CN1		/43.7	
	/43.6	-11A5-XE2		YE	-3A7-CN1		/43.6	

37

